



# Taipan/Taipan Y ECU and Spark software

**Tuner Manual**

**Revision 1.09**



## **INDEX**

INDEX	1
1 – Introduction	3
2 – Taipan/Taipan Y connectors	3
3 – Compatibilities	4
4 – Accessories: Handlebar Switch and UC Bridge	4
4.1 – Handlebar switch	5
4.1.1 – How to change Maps:	5
4.1.2 – How to apply corrections:	5
4.1.3 – How to use the Traction Control:	5
4.1.4 – How to activate the Launch Control:	6
4.1.5 – Configure the HBS as a Shift Light Module:	6
4.2 – UC Bridge	7
5 – ECU Available Configurations	8
6 – Spark Software	8
6.1 – Software overview	9
6.2 – Menu bar	9
6.2.1 – File	10
6.2.2 – ECU	12
6.2.3 – Configuration	13
6.2.4 – Map	13
6.2.5 – Live Measures	14
6.2.6 – Diagnostics	15
6.2.7 – Updates	17
6.2.8 – Options	17
7 – Icon bar	19
8 – Project view	20
8.1 – Configuration	21
8.2 – Parameters	21
8.2.1 – Motorcycle Setup	21
8.2.2 – Sensor Plausibility	21
8.2.3 – Timers	22
8.2.4 – Map switch	23
8.2.5 – Launch Control	23
8.2.6 – Pre-injection	24
8.3 – Strategies	25
8.3.1 – Drop sensor	25
8.3.2 – Fan control (Enduro bikes only)	26
8.3.3 – Injection strategy	27
8.3.4 – Injectors phase strategy	28
8.3.5 – Neutral strategy	28
8.3.6 – Quick shift	29
8.4 – Vb out	30
8.5 – CAN Configuration	30
8.5.1 – CAN parameters	30
8.6 – Sensors	30
8.6.1 – Spare channel #1 and #2	31
8.6.2 – Other sensors	31
8.7 – Maps	31
8.8 – Fuel	32
8.8.1 – Injection main #1 alpha-n(ms)	32
8.8.2 – Fuel injection user compensation table	33
8.8.3 – Injection main speed-density (ms)	35
8.8.4 – Injection crank correction (%)	36
8.8.5 – Pre-injection (ms)	37
8.8.6 – Compensations	37
8.8.7 – Injection BAP correction (%)	37
8.8.8 – Injection EWT correction (%)	38
8.8.9 – Injection IAT correction (%)	38
8.8.10 – Injector 1	39
8.8.10.1 – Injector 1 battery correction (ms)	39
8.8.10.2 – Injector 1 phase (phase°)	39
8.8.11 – Injector 2	39
8.8.11.1 – Injector 2 battery correction (ms)	40

8.8.11.2 – Injector 2 percentage (%)	40
8.8.11.3 – Injector 2 phase (phase°)	40
8.8.12 – Transient	41
8.8.12.1 – Injection opening transient correction.	41
8.8.12.2 – Injection closing transient correction.	41
8.9 – Ignition	41
8.10 – Compensations	42
8.10.1 – Ignition BAP correction (Advance °):	42
8.10.2 – Ignition EWT correction (Advance °)	43
8.10.3 – Ignition IAT correction (Advance °)	43
8.10.4 – Ignition dwell time (Taipan Y only)	44
8.11 – Launch control	44
8.11.1 – Injection launch control main table (ms)	45
8.11.2 – Ignition launch control main table (Advance (°))	45
8.12 – Quick shift	45
8.12.1 – Quick shift cut timetable (ms)	46
8.13 – Traction control	46
8.13.1 – Traction control strategy	47
8.13.2 – Activate the traction control strategy	48
8.14 – Expansions	49
9 – Data view – special key and visualization	49
9.1 - Table Format	49
9.2 - 2D Format	51
9.3 – 3D Format	51
10 – Live Measures view box	51
11 – Info bar	52
Appendix A – Taipan/Taipan Y ECU Part Numbers	53
Appendix B – ECU Taipan/Taipan Y dimensions and pinout	54
Appendix C – Harness CAN + Ext power for Solo2 DL	55
Appendix D – Main terms	56
Appendix E – Pre-injection	58
Appendix F – Injection crank correction (%)	59
Appendix G – Injection N battery correction	63
Appendix H – Injection BAP correction	64
Appendix I – Transient management	65
Appendix J – CAN Protocols	70

## **1 – Introduction**

**Taipan/Taipan Y** is the AiM ECU designed for off-road bikes.



The complete system includes:

- The Taipan/Taipan Y ECU.
- The optional Handlebar Switch.
- The optional USB CAN Bridge.

It is easily installable on most of the off-road bikes, as described in the Chapter 3.

## **2 – Taipan/Taipan Y connectors**



The Taipan/Taipan Y ECU has four connectors:

- The main connector, compatible with most of the off-road bikes
- A CAN connector, to be connected to the Handlebar Switch and to an external datalogger.
- A second CAN connector, to be connected to the UC Bridge, in order to communicate with the PC.
- A fourth connector, to be connected to spare sensors and eventually to a second injector.

**The Pinout is fully described in Appendix B.**


### **3 – Compatibilities**

The Taipan/Taipan Y ECU, Spark tuning software, and accessories, are compatible with many model brands and types; please refer to Taipan page, compatible models of AiM website at [www.aim-sportline.com](http://www.aim-sportline.com). This list is constantly updated.

### **4 – Accessories: Handlebar Switch and UC Bridge**

Taipan/Taipan Y has these accessories:

- Handlebar switch, the fastest way to apply strategies while on the motorcycle.
- UC Bridge: an USB to CAN dongle used for communication between the Taipan/Taipan Y ECU and Spark tuning software.



## **4.1 – Handlebar switch**



The Handlebar Switch is the best way for changing the behaviour of your motorcycle; it features 2 pushbuttons and 10 LEDs and manages the following settings:

- 1) Change running map.
- 2) Apply fuel corrections.
- 3) Activate traction control.
- 4) Activate launch control.

The lower pushbutton is used for selecting a feature, while the upper pushbutton is used for choosing one of the possibilities available in the selected feature.

Finally, as described in section 4.1.5, you may use the LEDs on the handlebar switch as a Shift Light Module: in this case, at the desired RPM value, the LEDs will start blinking, helping you in changing gear.

When the ECU is powered ON, the Handlebar Switch will display the running map. The example to the right shows that map 2 is the running map.



### **4.1.1 – How to change Maps:**

Push the lower button till when the MAP Led is enlightened in blue, then push the upper button for changing the running map. If the selected map is valid, the respective LED will remain lit, else it will otherwise return to the previously selected valid map.

### **4.1.2 – How to apply corrections:**

A Correction is the possibility to get a richer or leaner fuel mixture at different RPM ranges: low, mid, high. The RPM thresholds as well as the percentage apply along with the default value, are defined in a proper chapter in this manual (configuration-parameters- map switch – injector trims)

If you want to apply a correction:

- first push the lower pushbutton to select at which RPM range (lower, mid, or high) you want to set the correction.
- Then use the upper button to set it:
  - o Select Level 3 for No Correction
  - o Select Level 4 and 5 for a fatter mixture.
  - o Select Level 1 and 2 for a leaner mixture.

### **4.1.3 – How to use the Traction Control:**

**Traction control** is a system that aids in preventing driven wheel spin when excess power is applied.

To activate it:

keep pushed the lower button until the green LED beside the TC turns ON. If you want to de-activate it, press and hold the lower pushbutton again until the green LED turns OFF.

- 1) With the TC enabled, use the upper pushbutton to select the strength of the Traction Control strategy; with 1 being the minimum and 5 being the maximum.

Please note that the Traction Control must be enabled for the selected Map: this will be done during the ECU Map configuration.

#### **4.1.4 – How to activate the Launch Control:**

**Launch control** is an electronic aid to assist riders to accelerate from a standing start.

To activate it, press and hold both the upper and lower pushbuttons until the LED's blink red, indicating that the strategy is engaged.


Please, note that the Launch Control must be enabled in the selected map.

#### **4.1.5 – Configure the HBS as a Shift Light Module:**


A Shift light module is an array of LEDs that will begin flashing at a defined RPM value, aiding the rider in optimal shift points.

You may use the Handlebar Switch LEDs as a Shift Light after configuring as shown here.


- 1) Please, connect and link the HBS to the UC Bridge through the CAN Connection.



- 2) Open a new project and select the HBS image from the Create New Configuration menu as shown below.



After the selection you will see this project tree:



*Please, do not forget to click the Connect Icon.*

#### Shift light:

Shift lights Enabled: true or false, to set up if you want to have the shift lights on your HBS or not.

Shift lights RPM threshold: to set up the RPM value at which the LEDs will flash.

After configuring the HBS connect it to the ECU expansion connection.

## **4.2 – UC Bridge**



The **UC Bridge** is the connection between the CAN bus of the ECU and the USB port of your PC, and is available in 2 different licenses:

- **User license:** A Taipan/Taipan Y ECU comes with some basic maps that already give you better performances than the stock ones. Some highly professional tuners, all over the world, offer specific maps that may better fit your requirements, managing, for example, different exhaust systems, two injector kits, etc.

You need the UC Bridge for two functions:

- Transfer new and different maps to your ECU through the User License UC Bridge.
- Receive from the Taipan/Taipan Y ECU the diagnostic information.

- **Tuner license:** With this license the tuner can create maps, configurations, and strategies designed for the rider's motorcycle. The tuner can then flash the ECU directly, or send the file by email to allow the rider to download and flash their own ECU. All while preserving the tuners proprietary work with three layers of protection and security.

Then the tuner can flash them directly on the ECU or send them by e-mail to allow the rider to download and install all Maps in the ECU. This manual covers the use of the tuner license.



## 5 – ECU Available Configurations

Taipan/Taipan Y ECU is available in two different configurations:

- **Configured ECU:** An already configured ECU is dedicated to the desired brand and model motorcycle. You may change maps and configurations but cannot change brand or model motorcycle.
- **Blank ECU:** A Blank ECU can be configured for the brand/model motorcycle you desire, simplifying the stock management of the tuners. **Be Careful!** Once you have configured a blank ECU for a dedicated brand and model motorcycle, you have 24 hours for changing the configuration, then you cannot change it anymore: you will anyway be able to modify the maps written into your ECU, but not the brand nor model motorcycle for which you have configured it.

## 6 – Spark Software



Spark is the AIM software used to configure and calibrate Taipan/Taipan Y ECUs. This document explains in detail each available function you can use with this software, with a “tuner” license.


To use the software, you must connect at least the UC Bridge, otherwise you cannot create projects nor use all the functionalities of Spark.

Connecting the UC Bridge and the ECU you can create projects, read projects, write, and flash the ECU.


## 6.1 – Software overview

When you open the Spark software with UC Bridge connected, the first window appears as in the following picture. The six macro-areas here highlighted will be referred to as indicated here on the right. The following chapters describe every area in detail.

- Black Menu bar (1)
- Red Icon bar (2)
- Green Project view (3)
- Violet Data view (4)
- Blue Live Measures view box (5)
- Orange Info bar (6)




## 6.2 – Menu bar




This bar features all the available items that allow to manage the project, setup the ECU, monitor data.

Every item includes several functions listed here below.

Please, note that:


- **Connected** is intended to mean “physically connected”: An ECU is “connected” to the PC when connected to the UC Bridge and this last is connected to your PC.
- **Linked** means that the communication between the PC and the device is activated: this is done by clicking on the icon  on the icon bar.

### 6.2.1 – File



**New Empty project:** Using this command you can create a new project, that is the sum of configuration, maps, strategies, and other parameters. A list of available motorcycles will appear after the selection and selecting one of them will enable you to start. It is possible to create a project without connecting the ECU, but the UC Bridge must be connected to your PC.

This is the menu that will appear after the selection of starting a new project, then you can select the motorcycle type or the Handlebar Switch configuration.



**Open ECU project:** Open a previously saved project.


**Close project:** to close the open project.

**Manage project password** (shortcut icon  )


The tuner that has developed a project may protect it with a password: when a protected project is sent to a customer, only who has the password may open it and eventually modify it.

The tuner that develops a project may decide to give the possibility to send exclusively to one or to some ECU(s): in this case, he must create a crypted version of the project, depending upon the SERIAL NUMBER of the ECUs that may receive it.

In the “Manage ECU target list “area you can add or delete a target ECU using its serial number.




If a password is set when the project is reopened the password will be requested.



**Save:** to save the current project.


**Save ECU project As...:** to save a copy of the current project with a new name.

**Preferences:** To set up your country measurement units.



**Exit:** to close Spark.

## **6.2.2 – ECU**




**Read ECU (maps and configuration):** this command is used to read all the flashed maps and the configuration from the ECU.

To read the ECU maps and configuration you must follow these steps:

- Open a project, selecting the proper motorcycle.
- Connect and link your ECU.
- Read ECU.

**Note - the ECU comes with the base map OPEN:** if you have the Tuner UC Bridge you may read it and modify as you wish. If the ECU has maps produced by other professional tuners, and reasonably protected by a password, you are required to set the proper password for reading them.

**Write ECU:** This command is used to flash into the ECU the configuration and maps selected with a dedicated selection menu here below that appears after executing this command.



Two different CAN protocols are available:


- Tuner CAN Protocol
- User CAN Protocol

Both are fully described in Appendix J.

The first one, the Tuner CAN Protocol, is used when you need to send to the logger all the possible information managed by the ECU (66 channels) , and is useful when you are tuning a motorcycle. The second one, the User CAN Protocol, transmits only the most important channels (28 channels) and is to be chosen when you flash a configuration into the ECU of the customer.


### 6.2.3 – Configuration

**Read configuration from ECU:** This command is used to read the configuration from the ECU.



**Write configuration to ECU:** This command is used to flash the configuration to the ECU.


### 6.2.4 – Map



**Read running map from ECU:** This command is used to read the running map only.

**Write selected map to ECU:** This command is used to flash the desired map to the ECU.


After having selected this feature, the following image appears:



- select the desired map through the right click of your mouse.
- select the menu voice "Write Map".

Finally, you can clone the map on other maps, for future developments.


**Change active map:** the active map (the map that is now running) can be changed choosing from a dedicated selection menu.



**Read selected table:** a selected table can be read from the running map.

**Write selected table:** the selected table can be written to the running map.

### 6.2.5 – Live Measures



**Start Live Measures:** this option is used to start the Live Measures in the Live Measures view box, once the project is opened and the ECU is connected.

Device configuration details

ECU name	GasGas - MC 250F 2021
Number of maps	6
ECU model	COBRA
ECU serial number	9100108
Hardware version	ECU02C
Firmware version	0.5.6
Bootloader version	0.3.1
Production date	2020-12-10 16:41:47
Notes	Default configuration for GasGas - MC 250F 2021

INJ1 time	3.344 ms	ECT	70.0 °C	IGN	9.0 °	Sync err	0 #
INJ1 phase	-92.0 °	IAT	20.0 °C	INJ base	0.760 ms	Eng pos	Seek
INJ2 time	0.000 ms	V ign	0.000 V	RPM	0 rpm	Eng state	Stop
INJ2 phase	-360.0 °	λ	0.000 λ	TPS	0.0 %	Eng revs	0 #


Measures active | Progress...0% done | Live Measures correctly started

**Stop Live Measures:** stops the live measures in the Live Measures view box.

**Hide Live Measures panel:** This command hides the Live Measures view box and expands the data view area just above.

**Show Live Measures panel:** Shows the Live Measures view box.

## 6.2.6 – Diagnostics



**Read Freeze Fault from ECU:**

Once the project is opened and the ECU is linked, it is possible to read the diagnostic data in real time or after a session and check the faults of the engine and sensors. Saved faults can be exported in a .csv report file or deleted.



Clicking the command, two tabs appear. The Live faults tab (real time data) and the Freeze faults tab (errors saved). Every fault is reported associated to the hour meter in which it occurred.

Live faults


Freeze Faults (hour meter: 00:00:00)


Diagnostics	State
Injector 1 - Open Load	Ok
Injector 1 - Over Current	Ok
Injector 1 - Over Temperature	Ok
Injector 1 - Short to Ground	Ok
Fuel Pump - Open Load	Ok
Fuel Pump - Over Current	Ok
Fuel Pump - Over Temperature	Ok
Fuel Pump - Short to Ground	Ok
MIL led - Open Load	Ok
MIL led - Over Current	Ok
MIL led - Over Temperature	Ok
MIL led - Short to Ground	Ok
MAP sensor signal low	Ok
MAP sensor signal high	Error
TPS sensor signal low	Ok
TPS sensor signal high	Error
Battery voltage signal low	Ok
Battery voltage signal high	Ok
ECT sensor signal low	Ok
ECT sensor signal high	Error
Gear sensor signal low	Ok
Gear sensor signal high	Error
IAT sensor signal low	Ok
IAT sensor signal high	Error
Drop sensor signal low	Ok
Drop sensor signal high	Ok


Live faults

Freeze Faults (hour meter: 00:00:00)

Time (hh:mm:ss)	Description
00:00:00	IAT sensor signal high
00:00:00	Gear sensor signal high
00:00:00	ECT sensor signal high
00:00:00	TPS sensor signal high
00:00:00	MAP sensor signal high

If the Live Measures view box is activated, you can visualize the faults in real time. To activate Live Measures, press the Start Live Measure icon 

To save the faults in a CSV file press the bottom-right button 

To clear the faults list, press the bottom-left button 

**Read ECU/UC bridge identity:** read serial number, firmware version and hardware versions of both ECU and UC bridge. This is important info to maintain the software and devices aligned.


**Read Handlebar Switch identity:** read serial number, firmware, and configuration from Handlebar Switch (if HB Switch is connected


Here is the list of the possible sensor errors, coming from the ECU, that can be recognized by Spark (Injector 2 errors are present if there is the injector 2 and it is enabled):

- Injector 1 - Open Load
- Injector 1 - Over Current
- Injector 1 – Over Temperature
- Injector 1 – Short to Ground
- Fuel Pump – Open Load
- Fuel Pump – Over Current
- Fuel Pump – Over temperature
- Fuel Pump – Short to ground
- MIL led – Open load
- Mil led – Over current
- Mil led – Over Temperature

- Mil led – Short to ground
- MAP sensor signal low
- MAP sensor signal high
- TPS sensor signal low
- TPS sensor signal high.
- Battery voltage signal low.
- Battery voltage signal high.
- ECT sensor signal low.
- ECT sensor signal high.
- Gear sensor signal low.
- Gear sensor signal high.
- IAT sensor signal low.
- IAT sensor signal high.
- Drop sensor signal low.
- Drop sensor signal high.

### 6.2.7 – Updates





**Update UC Bridge firmware:** With project CLOSED and the UC Bridge connected you can update the firmware. First check if an update is present (icon on the right- icon section  ). If the update is present you can download it and then install it in this section.


**Update ECU Firmware:** With project CLOSED and ECU connected you can update the firmware. First check if an update is present (icon on the right- icon section). If the update is present, you can download it and then install it in this section.

**Update Handlebar Switch Firmware:** This section appears only if HB Switch is connected to the UC Bridge.

With project CLOSED and HBS connected you can update the firmware. First check if an update is present (icon on the right- icon section). If the update is present, you can download it and then install it.




### 6.2.8 – Options



**TPS Calibration:** this command is used to calibrate the Throttle position sensor.


First, please note that this command is only available if you are connected to the ECU, and you have an open ECU project.

By clicking the TPS calibration command, the following tab will appear:




The 'Sensor calibration' dialog box is shown with the 'Calibrate' tab selected. It contains three input fields: 'TPS live view' with the value '0.021 V', 'TPS 0.0%' which is empty, and 'TPS 100.0%' which is empty. Each of the latter two fields has a 'Set' button to its right. At the bottom, there is a checked checkbox labeled 'Update open project with new calibration', and two buttons: 'Cancel' and 'Write to ECU'.

The first row shows the TPS live measure expressed in volts. To calibrate the TPS, keep the throttle in the zero position (completely closed) and click “Set” in correspondence of TPS 0.0%. The value in volts, corresponding to the throttle zero position, will appear as shown in the example below:



The 'Sensor calibration' dialog box is shown after the first calibration step. The 'TPS 0.0%' field now contains the value '0.029 V' and its 'Set' button is highlighted in blue. The 'TPS live view' field still shows '0.029 V'. The 'TPS 100.0%' field remains empty. The 'Update open project with new calibration' checkbox is still checked, and the 'Cancel' and 'Write to ECU' buttons are at the bottom.

Subsequently, maintain the throttle in the 100% position (fully open) and click “Set” in correspondence of TPS 100.0%. The value in volts, corresponding to the throttle fully open position, will appear as shown in the example below:



The 'Sensor calibration' dialog box is shown after the second calibration step. The 'TPS 100.0%' field now contains the value '3.650 V' and its 'Set' button is highlighted in blue. The 'TPS 0.0%' field still contains '0.029 V'. The 'TPS live view' field now shows '3.650 V'. The 'Update open project with new calibration' checkbox is still checked, and the 'Cancel' and 'Write to ECU' buttons are at the bottom.

























Afterwards, by clicking “Write to ECU” the TPS calibration is flashed to the ECU. Keep in mind that, if the checkbox “Update open project with new calibration” is marked, the TPS calibration will be updated also to the open project.

**Reset engine hour meter:** This command is used to reset the engine hour meter.

## 7 – Icon bar

This bar features some shortcut icons for the most common commands. Some of these icons are activated only if the project is open, others when the project is open, and the ECU linked.




	Create a New Project		View diagnostic fault. No fault is detected
	Open Project		View diagnostic fault. One or more faults are detected
	Save Project		Show Live Measure panel
	Manage Project Password		Hide Live Measure panel
	Link to ECU (in order to work on that specific ecu connected)		Web update is present and web connection is detected
	Unlink from ECU		Web update is ready for installation and web connection is detected
	ECU configuration info. Before connecting the ECU, this command lets the user know for which motorcycle model the ECU is configured.		No web update and, web connection is detected
	Read configuration from ECU		downloading web update, and web connection is detected
	Read running Map from ECU		No web update, and web connection is not detected
	Flash configuration to ECU		Web update is present, and web connection is not detected
	Flash running map to ECU		
	Start Live Measure		
	Stop Live Measure		Direct link to AiM web site

## 8 – Project view

The **Project** is the sum of all the 6 maps and the configuration that describe the behaviour of a bike. In this chapter we explain how to develop and modify a project.

Once the project has been opened, or a new project has been created, the software shows the image below. In the Project tree view the software shows:

- Motorcycle model.
- Configuration.
- The six Maps.
- Expansion: The Handlebar Switch and related parameters.



The Project tree can be expanded by pressing the plus symbol, each part includes several submenus that will be explored in the following chapters.

After having connected your ECU, you can find the ECU Info section:

- the motorcycle model.
- the serial number
- the hardware and firmware version.
- The production date.

Diagnostics Updates Options	
Device configuration details	
ECU name	GasGas - MC 250F 2021
Number of maps	6
ECU model	COBRA
ECU serial number	9100108
Hardware version	ECU02C
Firmware version	0.5.6
Bootloader version	0.3.1
Production date	2020-12-10 16:41:47
Notes	Default configuration for GasGas - MC 250F 2021

## **8.1 – Configuration**

The configuration section lets you manage all the parameters that are not directly related to the engine performance:


- second injector.
- sensors plausibility.
- kill switch and MIL lamp timers.
- map switch.
- parameters for launch control strategy.
- pre injection.
- RPM limiters.
- drop sensor.
- strategies for injection, injection phase, neutral and quick shift
- Vb out

These features are collected in the following three groups:

- Parameters
- CAN configuration
- Sensors

## **8.2 – Parameters**

### **8.2.1 – Motorcycle Setup**



In this section you can enable the second injector if present.

**Please note:** after having enabled the second injector, you must define the strategy for activating it, filling the proper injector tables located in the Map section -> Fuel -> Injector (1 and 2)

### **8.2.2 – Sensor Plausibility**

Here you can set the acceptability output range of every sensor connected to the ECU.

When a sensor gives an output out of range, the default value is associated to the sensor:

TPS default value: 0.

ECT default value: 70°C.

IAT default value: 20°C.

MAP default value: 1.000 bar

BARO default value: 1.013 bar

GasGas - MC 250F 2021

- Configuration
  - Parameters
    - Bike setup
    - Sensor plausibility**
    - Timers
  - Map switch
    - Injection trims
  - Launch control
  - Pre-injection\*
  - RPM limiter
  - Strategies
    - Drop sensor
    - Injection strategy
    - Injectors phase strategy
    - Neutral strategy
    - Quickshift
  - Vb out
  - CAN configuration
  - Sensors
- Map 1 (Default map 1)**
- Map 2 (Default map 2)
- Map 3 (Default map 3)
- Map 4 (Default map 4)
- Map 5 (Default map 5)
- Map 6 (Default map 6)
- Expansions

Sensor plausibility details

EWT sensor min plausible value (V):	EWT sensor max plausible value (V):
0.100	4.600
IAT sensor min plausible value (V):	IAT sensor max plausible value (V):
0.100	4.600
MAP sensor min plausible value (V):	MAP sensor max plausible value (V):
0.200	4.000
TPS sensor min plausible value (V):	TPS sensor max plausible value (V):
0.250	4.800
Gear sensor min plausible value (V):	Gear sensor max plausible value (V):
0.200	4.000
Drop sensor min plausible value (V):	Drop sensor max plausible value (V):
0.000	5.000
Min map switch plausible value (V):	Max map switch plausible value (V):
0.000	5.000
Min spare 1 plausible value (V):	Max spare 1 plausible value (V):
0.000	5.000
Min spare 2 plausible value (V):	Max spare 2 plausible value (V):
0.000	5.000

Just a few words about the **Min Map Switch range sensor**: this field is intended to define the range of the Min Map Switch, and appears only in the KTM/Husqvarna project, because only these models have the analogue switch input.



### 8.2.3 – Timers

GasGas - MC 250F 2021

- Configuration
  - Parameters
    - Bike setup
    - Sensor plausibility
    - Timers**
  - Map switch
    - Injection trims
  - Launch control

Timers details

MIL test on timer (s):
2.000
Kill switch debounce time (s):
0.3

Here you can set timers for MIL lamp and kill switch.

- MIL test on timer(s): time that MIL (Malfunction Indicator Lamp) is on for initial check.
- Kill switch debounce time(s): minimum time the kill switch is pressed to activate the motorcycle stop.

## 8.2.4 – Map switch

In this section you can set the configuration parameters of the Handlebar switch.

### - Injectors trims:

In this section you can set the percentage steps, the level and the ranges of the fuel corrections that will be set by the Handlebar Switch.

For example, if you set all the step percentages to 2%:

At Trim injector correction 3, I will not have correction.

At Trim injector correction 4 and 5, I will have a fuel correction of + 2% or +4%

At Trim injector correction 2 and 1 I will have a fuel correction of -2% or -4%

Finally, the thresholds between Low and Mid RPM and between Mid and High RPM are set in the dedicated fields.

## 8.2.5 – Launch Control

**Launch control** is an electronic aid to assist riders to accelerate from a standing start.

This strategy has three different states: ENGAGED, ON and OFF. To ENGAGE (that means motorcycle ready to go but still stationary) this strategy the motorcycle needs to be under these conditions:

- The launch control is enabled in the running map.
- The launch control is requested by pushing the launch control button on the Handlebar Switch.
- The RPM must be less than the Maximum RPM value set for launch control activation.
- The bike TPS must be less than the Maximum TPS (threshold) value for launch control activation (%)



- To be in neutral or first gear

Only if these conditions are respected the strategy will be engaged.

When the Launch control is engaged, you may limit the RPM value at a configurable RPM value, set in the field.

- Temporary RPM limiter

The RPM limiter is disabled at the motorcycle starting when the RPM has a drop that you may define in the field:

- Engine speed gap (Rpm)

When the motorcycle begins to move, the Launch Control strategy turns ON and the temporary launch control RPM limiter is activated till when an RPM drop is detected. At this point, the temporary launch control RPM limiter is deactivated, the normal RPM limiter comes back, and the Launch Control table is used.

The Launch Control is deactivated in two different ways:

Deactivate LC after a pre-defined amount of time


Launch control deactivation time - Set the seconds after which LC turns off.

Deactivate LC at pre-defined gear

Launch control deactivation gear - Set the gear where LC turns off.

You can find the launch control tables in Map -> Launch control (injection launch control main table – ignition launch control main table)

## 8.2.6 – Pre-injection



The **pre-injection** is an early amount of fuel injected at the very first crankshaft instants to clean the tubes and improving the fuel passage.

It is possible to enable the pre-injection, while you may set the quantity of injected fuel, in dependence of the water temperature, in the table at:

Map chosen - > Fuel -> Pre-injection.

## RPM Limiter

GasGas - MC 250F 2021
Configuration
Parameters
Bike setup
Sensor plausibility
Timers
Map switch
Injection trims
Launch control
Pre-injection\*
RPM limiter
Strategies
Vb out
CAN configuration
Sensors
Map 1 (Default map 1)
Map 2 (Default map 2)
Map 3 (Default map 3)
Map 4 (Default map 4)
Map 5 (Default map 5)
Map 6 (Default map 6)

RPM limiter details

Engine speed limiter 1 (rpm):	Engine speed limiter gap gear 1 (rpm):
14500	50
Engine speed limiter 2 (rpm):	Engine speed limiter gap gear 2 (rpm):
14500	50
Engine speed limiter 3 (rpm):	Engine speed limiter gap gear 3 (rpm):
14500	50
Engine speed limiter 4 (rpm):	Engine speed limiter gap gear 4 (rpm):
14500	50
Engine speed limiter 5 (rpm):	Engine speed limiter gap gear 5 (rpm):
14500	50
Engine speed limiter 6 (rpm):	Engine speed limiter gap gear 6 (rpm):
14500	50

Here you may set different RPM threshold per every map.

Beside the limiter values, you may define the RPM gap, in order to define at which RPM value to exit from limiter strategy for each map.

## 8.3 – Strategies

### 8.3.1 – Drop sensor

GasGas - MC 250F 2021
Configuration
Parameters
Bike setup
Sensor plausibility
Timers
Map switch
Injection trims
Launch control
Pre-injection\*
RPM limiter
Strategies
Drop sensor\*
Injection strategy
Injectors phase strategy
Neutral strategy
Quickshift

Drop sensor details
Drop sensor enabled:
True
Drop sensor kill time (s):
10.0

You can set the parameters for the Drop sensor, the sensor used for evaluating the bike inclination.


- Drop sensor enabled: False/True – to enable the drop sensor signal.
- Drop sensor kill time - if the drop sensor is enabled, select the time to wait before the engine is killed after the drop sensor signal has been triggered.

Please note that this sensor is not present in the Honda bikes, so, in case of Honda projects, this section is not available.


### 8.3.2 – Fan control (Enduro bikes only)

Fan control parameters are to set FAN control intervention temperature; this option is only available on Enduro bikes.

- Start fan if engine temperature above (°C): if engine temperature exceeds this threshold the cooling fan switches on.
- Stop fan if engine temperature below(°C): with FAN control active, if and only if engine temperature drops below the fixed threshold, cooling fan switches off



### 8.3.3 – Injection strategy



The screenshot displays the configuration interface for a GasGas MC 250F 2021. On the left, a tree view shows the configuration structure: Configuration > Parameters > Map switch > Injection trims > Launch control > Pre-injection\* > RPM limiter > Strategies > Drop sensor\* > **Injection strategy** (highlighted). On the right, the 'Injection strategy details' panel shows four adjustable parameters:

- Closing DTPS minimum value for second injector exclusion strategy (%/s): -20000
- Fuel percentage going to main injector (%): 100
- Engine speed threshold to switch from speed density to alpha/n (rpm): 0
- TPS threshold to switch from speed density to alpha/n (Tps (%)): 0.0

In this section it is explained how to manage the second injector during a rapid throttle closure.

The second injector is generally positioned above the throttle, in order to have a better air/fuel mixture at high RPM /throttle range.

After a rapid throttle closure, a quantity of fuel may remain nearby the throttle valve, and, at the next throttle rapid opening, may produce a very fat mixture inside the cylinder.

To avoid this problem, with Taipan/Taipan Y you can set the fuel percentage that passes through the main injector after a fast TPS closing, helping to keep the fuel/air ratio optimal even in this situation.

The parameters to be set are:

- **Closing DTPS** (TPS closing speed) injector exclusion strategy (%/s): TPS closing speed per second over which to start the strategy.
- **Fuel percentage going to main injector** (%) when the previous condition related to the closure of the DTPS is respected.

To set up the **injector 1** fuel values go to map -> fuel -> injector 1 (injector 1 battery corrections – injector 1 phase)

To set up the **injector 2** fuel values go to map -> fuel -> injector 2 (injector 2 battery corrections - injector 2 percentage - injector 2 phase)

The next two parameters that define the Injection Strategy are intended to decide which table is to be used for establishing the amount of gasoline to be injected:

There are two different ways for calculating the amount of gasoline used in every active phase:


- In dependence upon the amount of aspired air, Speed – density, calculated from the MAP sensor and RPM.
- In dependence upon the throttle angle (alpha) and RPM.

The first method gives a more precise idea of the oxygen available for the combustion, so let us calculate the amount of gasoline necessary for getting the desired lambda value but may be used only when the RPM value is low and the TPS is partially open. Over an RPM threshold and a TPS threshold, that you may define here, it is better to use the second method.

So, when RPM and the TPS are under the set thresholds, the Speed Density/RPM map is used, else the Throttle angle (alpha) / RPM map is used. The parameters to be set here are:

- RPM threshold to switch from speed density to alpha/n table (RPM)
- TPS threshold to switch from speed density to alpha/n table (%)


### 8.3.4 – Injectors phase strategy



It is possible to set, for every injector, the injection phase as:

- the start of injection or
- the end of injection.

### 8.3.5 – Neutral strategy



By default, the Map number 6 is dedicated to the neutral strategy.  
You can choose how to engage this map in the different ways:

- Strategy OFF: the strategy is disabled.
- Use neutral sensor or gear sensor: if the motorcycle has a neutral or gear sensor and the neutral is detectable, once neutral is engaged the map is automatically changed to map 6, otherwise is changed to the previous default map.
- Use external switch: in this case a bi-stable switch can be plugged in, only once the switch is active the map is changed to map 6.

### 8.3.6 – Quick shift

The screenshot shows the configuration interface for a GasGas MC 250F 2021. On the left is a tree view of the configuration options, with 'Quickshift\*' selected under the 'Strategies' folder. On the right, the 'Quickshift details' panel contains the following settings:

Quickshift details	
Quickshift operating strategy:	Quickshift blind time (ms):
Enabled with ignition and injection cut	500
Minimum engine speed for quickshift activation (rpm):	Minimum TPS value for quickshift activation (Tps (%)):
3000	5.0
External quickshift sensor channel:	
Not configured	

It is possible to set-up the quick shift strategy, in order to reduce the time of power loss between gear changes.  
This setting works in combination with a proper quick shift table, to be defined in every map (map -> quick shift)

The Quick Shift may be:

- Quick shift DISABLED.
- Quick shift ENABLED with ignition cut only.
- Quick shift ENABLED with ignition and injection cut.


If the Quick Shift strategy is ENABLED, you must set these parameters:

- Minimum RPM for quick shift activation.
- Minimum TPS value for quick shift activation (%)

Only if TPS and RPM are greater than the thresholds this strategy is active.

- Quick shift blind time (msec): Once the strategy is active for the calculated time from the dedicated table, another shift activation is inhibited for this blind time.
- External quick shift sensor channel: in case your bike must have an external switch, used to read the shift status, connected to one of the two spare inputs of the Taipan/Taipan Y ECU.

## 8.4 – Vb out




The Taipan/Taipan Y ECU can be enabled to generate the Vb (12V power supply) in order to power an external device (i.e., datalogger).

- Vb out enabled: False/True.
- Vb out delay time(s) - the Vb out is generated only if the engine is running and is phased. If these conditions are met, once the delay time expires the ECU starts supplying power externally.

## 8.5 – CAN Configuration


### 8.5.1 – CAN parameters



This section is activated when the Expansions section (the last section of the project tree) is set to true. If the section is set to false, you can choose to have a CAN output or not (aux Can enabled / disabled)

## 8.6 – Sensors

In this section it is possible to define external sensors or switches eventually connected to the two auxiliary analogue inputs.




### 8.6.1 – Spare channel #1 and #2

The Taipan/Taipan Y ECU offers the possibility to manage two spare sensors. Each of them may be enabled and configured, thanks to a dedicated table with 16 breakpoints. For each entry, the voltage and the corresponding sensor's measure must be defined.

### 8.6.2 – Other sensors

This section is thought to set up on a motorcycle a sensor that is not a stock sensor.

## 8.7 – Maps



This is the section where the six ECU maps and strategies are defined. Please select a map from the Tree View and look at its details and strategies in the Data View window.

**Please note: in the actual chapter the maps, and their meanings, are introduced. In Chapter 9 it will be explained how to manage the entry points.**

#### - Map strategy to apply (gear based or not):

The Map Strategy may be:

- Gear based.
- Not Gear based.

In the first case, there is a different main table for injection and ignition per every gear.

#### - Traction Control Strategy:

In case the Traction Control is ENABLED, for every map, the ECU has dedicated parameters, to be described later in this manual.

#### - Launch Control:

In case the Launch Control is ENABLED, for every map, the ECU has a dedicated launch control main table.



## Map 1 (Default map 1)

- Fuel
- Ignition
- Launch control
- Quickshift
- Traction control

For every map you must set the following tables:

- Fuel
- Ignition
- Launch control (if enabled)
- Quick shift (if enabled)
- Traction control (if enabled)

## 8.8 – Fuel

### 8.8.1 – Injection main #1 alpha-n(ms)

<

X axis: RPM – 64 breakpoints

Y axis: TPS (%) – 10 breakpoints

Entry points: Injection Time (ms)

This map defines the injection time, in ms, in dependence upon the RPM and Throttle position.

In case of gear dependant setting, this table is applied only to the first gear, otherwise is applied for all gears.


The map can also be managed with a 2D view providing a quicker overview of the calibration.

In case the Map Strategy is Gear based, you may also fill the same maps for the other gears.

### 8.8.2 – Fuel injection user compensation table

From Spark 1.1.8 onwards there is also the possibility with both user and tuner license to correct the injection/ignition base maps.

More into details, below each map there are two user compensation tables as shown in the figure below:



- **Injection user compensation:**

The fuel injection user compensation is a correction table where you can correct the injection time in percentage for each map, an example of an empty table is shown below. The correction range available is between +20% and -10%.

This means that if you are adding a + 10% in a point of this table the main injection map is corrected in that exact point by a 10% more of injection time.

Table	2D	3D
-------	----	----

Map 1 - Fuel.Injection user compensation (%)																
Tps (%)rpm	1000	2000	3000	4000	5000	6000	7000	8000	9000	10000	11000	12000	13000	14000	15000	16000
10.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0
20.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0
30.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0
40.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0
50.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0
60.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0
70.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0
80.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0
90.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0
100.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0

X: rpm (min: 0, max: 20000)  
Y: Tps (%) (min: 0.0, max: 100.0)  
f(X, Y): % (min: -10.0, max: 20.0)

☐ Lock breakpoints

- Ignition user compensation:

The ignition user compensation table is a correction table where you can correct the advance in degrees for each map. The thresholds to be respected are between 3.0 ° and -5.0° in term of advance. In other words, if you are adding in a point a -2° of advance the main ignition map is corrected by a -2° of advance in that exact point resulting in a delay in terms of ignition advance degrees. An example of an empty ignition user compensation table is shown below:

Table

2D

3D

Map 1 - Ignition.Ignition user compensation (Advance (°))

Tps (%)rpm	1000	2000	3000	4000	5000	6000	7000	8000	9000	10000	11000	12000	13000	14000	15000	16000
10.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0
20.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0
30.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0
40.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0
50.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0
60.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0
70.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0
80.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0
90.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0
100.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0

X: rpm (min: 0, max: 20000)  
Y: Tps (%) (min: 0.0, max: 100.0)  
f(X, Y): Advance (°) (min: -5.0, max: 3.0)

☐ Lock breakpoints

Please remember that, to apply the changes made to the user compensation tables you need to connect the UC-bridge between the PC and the ECU and write the previously modified map using the command “Write ECU” or using the shortcut ALT+MAIUSC+E.

### 8.8.3 – Injection main speed-density (ms)

Injection trims

Launch control

Pre-injection\*

RPM limiter

Strategies

Drop sensor\*

Injection strategy

Injectors phase strategy

Neutral strategy\*

Quickshift\*

Vb out

CAN configuration

CAN parameters

Sensors

Engine water temperature sensor

Gear sensor

Intake air temperature sensor

Manifold air pressure sensor

Spare channel #1

Spare channel #2

Throttle position sensor

Map 1 (Default map 1)

Fuel

Injection main #1

Injection main speed-density

Injection crank correction

Table

2D

3D

Map 1 - Fuel.Injection main speed-density (ms)

kPa\rpm	250	500	750	1000	1250	1500	1750	2000	2250	2500	2750	3000	3250	3500	3750	4000	4250	4500	4750	5000	5250	5500	5750
49.0	0.000	0.000	0.000	0.000	0.000	0.000	0.000	0.000	0.000	0.000	0.000	0.000	0.000	0.000	0.000	0.000	0.000	0.000	0.000	0.000	0.000	0.000	0.000
54.4	0.000	0.000	0.000	0.000	0.000	0.000	0.000	0.000	0.000	0.000	0.000	0.000	0.000	0.000	0.000	0.000	0.000	0.000	0.000	0.000	0.000	0.000	0.000
59.8	0.000	0.000	0.000	0.000	0.000	0.000	0.000	0.000	0.000	0.000	0.000	0.000	0.000	0.000	0.000	0.000	0.000	0.000	0.000	0.000	0.000	0.000	0.000
65.2	0.000	0.000	0.000	0.000	0.000	0.000	0.000	0.000	0.000	0.000	0.000	0.000	0.000	0.000	0.000	0.000	0.000	0.000	0.000	0.000	0.000	0.000	0.000
70.6	0.000	0.000	0.000	0.000	0.000	0.000	0.000	0.000	0.000	0.000	0.000	0.000	0.000	0.000	0.000	0.000	0.000	0.000	0.000	0.000	0.000	0.000	0.000
76.0	0.000	0.000	0.000	0.000	0.000	0.000	0.000	0.000	0.000	0.000	0.000	0.000	0.000	0.000	0.000	0.000	0.000	0.000	0.000	0.000	0.000	0.000	0.000
81.4	0.000	0.000	0.000	0.000	0.000	0.000	0.000	0.000	0.000	0.000	0.000	0.000	0.000	0.000	0.000	0.000	0.000	0.000	0.000	0.000	0.000	0.000	0.000
86.8	0.000	0.000	0.000	0.000	0.000	0.000	0.000	0.000	0.000	0.000	0.000	0.000	0.000	0.000	0.000	0.000	0.000	0.000	0.000	0.000	0.000	0.000	0.000
92.2	0.000	0.000	0.000	0.000	0.000	0.000	0.000	0.000	0.000	0.000	0.000	0.000	0.000	0.000	0.000	0.000	0.000	0.000	0.000	0.000	0.000	0.000	0.000
98.0	0.000	0.000	0.000	0.000	0.000	0.000	0.000	0.000	0.000	0.000	0.000	0.000	0.000	0.000	0.000	0.000	0.000	0.000	0.000	0.000	0.000	0.000	0.000

- X-Axis: RPM

- Y-Axis: MAP (Manifold Air Pressure).
- Entry Point: Injection Time in ms.

This map represents an alternative way to calibrate the ECU: depending upon the manifold air pressure (MAP) sensor, guarantees a better tuning at low RPM and low TPS opening. it is applied when the conditions under the Speed density strategy (Configuration -> Parameters -> Strategies -> Injection strategy) are met, so when RPM and TPS are under the set thresholds.

#### 8.8.4 – Injection crank correction (%)

Injection trims

Launch control

Pre-injection\*

RPM limiter

Strategies

Drop sensor\*

Injection strategy

Injectors phase strategy

Neutral strategy\*

Quickshift\*

Vb out

CAN configuration

CAN parameters

Sensors

Engine water temperature sensor

Gear sensor

Intake air temperature sensor

Manifold air pressure sensor

Spare channel #1

Spare channel #2

Throttle position sensor

Map 1 (Default map 1)

Fuel

Injection main #1

Injection main speed-density

Injection crank correction

Pre-injection

Compensations

Injector 1

Injector 2

Transient

Table

2D

3D

Map 1 - Fuel Injection crank correction (%)

"Fv	0	1	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16	18	120	300
-40.0	152.0	155.0	158.0	159.0	159.0	158.5	157.8	154.9	150.8	145.7	140.9	137.7	137.7	137.5	137.5	137.5	137.5	141.5	145.5	145.5
-22.0	142.0	145.0	148.0	149.0	149.0	148.5	147.8	144.9	140.8	135.7	130.9	127.7	127.7	127.5	127.5	127.5	127.5	131.5	135.5	135.5
-4.0	132.0	135.0	138.0	139.0	139.0	138.5	137.8	134.9	130.8	125.7	120.9	117.7	117.7	117.5	117.5	117.5	117.5	121.5	125.5	125.5
14.0	122.0	125.0	128.0	129.0	129.0	128.5	127.8	124.9	120.8	115.7	110.9	107.7	107.7	107.5	107.5	107.5	107.5	111.5	115.5	115.5
32.0	109.0	113.0	117.0	119.0	120.0	119.5	117.8	114.9	109.8	103.7	95.9	89.7	88.7	88.5	88.5	88.5	89.5	96.5	102.5	102.5
50.0	97.0	101.0	105.0	108.0	110.0	109.5	108.8	104.9	99.8	91.7	84.9	78.7	75.7	74.5	74.5	74.5	76.5	82.5	88.5	88.5
68.0	82.0	87.0	92.0	95.0	97.0	97.5	95.8	92.9	86.8	78.7	69.9	64.7	63.7	63.5	63.5	63.5	64.5	67.5	69.5	69.5
86.0	53.0	59.0	63.0	66.0	67.0	66.5	63.8	59.9	55.8	50.7	45.9	40.7	35.7	33.5	32.5	32.5	32.5	33.5	38.5	45.0
104.0	26.0	28.0	30.0	31.0	31.0	33.0	38.0	42.0	45.0	46.0	43.0	38.0	25.0	15.0	15.0	15.0	15.0	17.0	23.0	30.0
122.0	22.0	24.0	27.0	27.0	26.0	27.0	33.0	39.0	43.0	44.0	43.0	38.0	25.0	15.0	15.0	15.0	15.0	15.0	15.0	30.0
131.0	22.0	24.0	27.0	27.0	26.0	27.0	33.0	39.0	43.0	44.0	43.0	38.0	25.0	15.0	15.0	15.0	15.0	15.0	15.0	0.0
140.0	20.0	21.0	23.0	24.0	22.0	22.0	28.0	34.0	38.0	39.0	38.0	33.0	25.0	15.0	15.0	15.0	15.0	15.0	15.0	0.0
149.0	20.0	21.0	23.0	24.0	22.0	22.0	28.0	34.0	38.0	39.0	38.0	33.0	25.0	15.0	15.0	15.0	15.0	15.0	15.0	0.0
158.0	10.0	9.0	12.5	10.5	10.5	11.0	14.0	17.0	19.0	19.5	19.0	16.5	12.5	7.5	7.5	7.5	7.5	7.5	7.5	0.0
167.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0
176.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0
185.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0
194.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0
203.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0

- X-axis: Number of Revolutions (REV)
- Y-axis Engine Coolant Temperature ECT.
- Entry Point: injection percentual correction to apply at the main injection table.

This table is only applied at the engine crank for the maximum number of revolutions (end point of Revolution X-axis).

**This strategy is deeply explained in Appendix F.**

### 8.8.5 – Pre-injection (ms)

Injection trims

Launch control

Pre-injection\*

RPM limiter

Strategies

Drop sensor\*

Injection strategy

Injectors phase strategy

Neutral strategy\*

Quickshift\*

Vb out

CAN configuration

CAN parameters

Sensors

Engine water temperature sensor

Gear sensor

Intake air temperature sensor

Manifold air pressure sensor

Spare channel #1

Spare channel #2

Throttle position sensor

Map 1 (Default map 1)

Fuel

Injection main #1

Injection main speed-density

Injection crank correction

Pre-injection

Compensations

Table

2D

3D

Map 1 - Fuel.Pre-injection (ms)

ms\°F	5.0	26.6	32.0	37.4	48.2	57.2	68.0	75.2	93.2	102.2	150.8	152.6	179.6	210.2	253.4	285.8
	0.000	0.000	0.000	0.000	0.000	0.000	0.000	0.000	0.000	0.000	0.000	0.000	0.000	0.000	0.000	0.000

- X-axis: Engine Coolant Temperature ECT
- Entry Point: pre-injection durations in ms.

If Pre-injection strategy is enabled, this table is activated by the very first movement of the crankshaft and is applied just before the intervention of all the other tables (injection main / injection crank corrections).

**This strategy is deeply explained in Appendix E.**

### 8.8.6 – Compensations

All these tables are referred as corrections as to the main injection table.

### 8.8.7 – Injection BAP correction (%)

- Injection strategy
- Injectors phase strategy
- Neutral strategy\*
- Quickshift\*
- Vb out
- CAN configuration
- CAN parameters
- Sensors
  - Engine water temperature sensor
  - Gear sensor
  - Intake air temperature sensor
  - Manifold air pressure sensor
  - Spare channel #1
  - Spare channel #2
  - Throttle position sensor
- Map 1 (Default map 1)
  - Fuel
    - Injection main #1
    - Injection main speed-density
    - Injection crank correction
    - Pre-injection
    - Compensations
      - Injection BAP correction
      - Injection EWT correction
      - Injection IAT correction

Table

2D

3D

Map 1 - Fuel.Compensations.Injection BAP correction (%)

%kPa	40.0	45.0	50.0	55.0	60.0	65.0	70.0	75.0	80.0	85.0	90.0	95.0	100.0	105.0	110.0	120.0
	-50.0	-50.0	-50.0	-45.0	-40.0	-37.0	-32.0	-27.0	-22.0	-17.0	-10.0	-5.0	0.0	0.0	5.0	10.0

- X-axis: Barometric pressure
- Entry Point: percentage of fuel correction.

### 8.8.8 – Injection EWT correction (%)




Table 2D 3D

**Map 1 - Fuel.Compensations.Injection EWT correction (%)**

%\°F	-22.0	-4.0	14.0	32.0	50.0	68.0	86.0	104.0	122.0	140.0	158.0	176.0	194.0	212.0	230.0	248.0
	80.0	70.0	65.0	60.0	55.0	40.0	30.0	25.0	18.0	15.0	0.0	0.0	0.0	0.0	0.0	0.0

- X-axis: Engine Water Temperature
- Entry Point: percentage of fuel correction.

### 8.8.9 – Injection IAT correction (%)




Table 2D 3D

**Map 1 - Fuel.Compensations.Injection IAT correction (%)**

%\°F	-22.0	-4.0	14.0	32.0	50.0	68.0	86.0	104.0	122.0	140.0	158.0	176.0	194.0	194.0	194.0	194.0
	10.0	8.0	6.0	4.0	2.0	1.0	0.0	-1.0	-2.0	-3.0	-4.0	-5.0	-6.0	-7.0	-8.0	-9.0

- X-axis: Intake Air temperature
- Entry Point: percentage of fuel correction.

## 8.8.10 – Injector 1

### 8.8.10.1 – Injector 1 battery correction (ms)

GasGas - MC 250F 2021

Configuration

Parameters

CAN configuration

Sensors

Map 1 (Default map 1)

Fuel

Injection main #1

Injection main speed-density

Injection crank correction

Pre-injection

Compensations

Injection BAP correction

Injection EWT correction

Injection IAT correction

Injector 1

Injector 1 battery correction

Injector 1 phase

Injector 2

Transient

Ignition

Quickshift

Table

2D3D

Map 1 - Fuel.Injector 1.Injector 1 battery correction (ms)

ms\V	8.000	8.500	9.000	9.500	10.000	10.500	11.000	11.500	12.000	12.500	13.000	13.500	14.000	14.500	15.000	15.500
	2.500	2.336	2.171	2.007	1.842	1.678	1.513	1.349	1.184	1.020	1.020	1.020	1.000	0.893	0.893	0.893

- X-axis: battery voltage
- Entry Point: injection time offset in ms.

This strategy is deeply explained in Appendix G.

### 8.8.10.2 – Injector 1 phase (phase°)

File

ECU

Configuration

Map

Live Measures

Diagnostics

Updates

Options

This table is based on X-axis with RPM and Y-axis with TPS. Depending on the injector operating strategy selected (Configuration -> Parameters -> Strategies) the entry value in this table is the end or the start angle of the injection phase.

X-axis = RPM.

Y-axis = TPS.

Entry Point = end or the start angle of the injection phase.

## 8.8.11 – Injector 2

This section appears only if you have an OEM 2<sup>nd</sup> injector or if you have selected the proper option in Configuration ->Strategies-> Motorcycle setup)



### 8.8.11.1 – Injector 2 battery correction (ms)

GasGas - MC 250F 2021	Table 2D 3D																
	Map 1 - Fuel.Injector 2.Injector 2 battery correction (ms)																
Configuration	ms\V	8.000	8.500	9.000	9.500	10.000	10.500	11.000	11.500	12.000	12.500	13.000	13.500	14.000	14.500	15.000	15.500
Map 1 (Default map 1)		0.000	0.000	0.000	0.000	0.000	0.000	0.000	0.000	0.000	0.000	0.000	0.000	0.000	0.000	0.000	0.000
Fuel																	
Injection main #1																	
Injection main speed-density																	
Injection crank correction																	
Pre-injection																	
Compensations																	
Injector 1																	
Injector 2																	
Injector 2 battery correction																	
Injector 2 percentage																	
Injector 2 phase																	
Transient																	
Ignition																	
Quickshift																	

- X-axis: battery voltage
- Entry Point: injection time offset in ms.

This strategy is deeply explained in Appendix G.

### 8.8.11.2 – Injector 2 percentage (%)

GasGas - MC 250F 2021	Table 2D 3D																										
	Map 1 - Fuel.Injector 2.Injector 2 percentage (%)																										
Configuration	Tps (%)\rpm	250	500	750	1000	1250	1500	1750	2000	2250	2500	2750	3000	3250	3500	3750	4000	4250	4500	4750	5000	5250	5500	5750	6000		
Map 1 (Default map 1)	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0
Fuel																											
Injection main #1																											
Injection main speed-density																											
Injection crank correction																											
Pre-injection																											
Compensations																											
Injector 1																											
Injector 2																											
Injector 2 battery correction																											
Injector 2 percentage																											
Injector 2 phase																											
Transient																											
Ignition																											
Quickshift																											
Map 2 (Default map 2)																											
Map 3 (Default map 3)																											
Map 4 (Default map 4)																											
Map 5 (Default map 5)																											
Map 6 (Default map 6)																											
Expansions																											

This table defines the percentual repartition between the two injectors.

X-axis = RPM.

Y-axis = TPS.

Entry Point = percentage of the fuel to the second injector

### 8.8.11.3 – Injector 2 phase (phase°)

GasGas - MC 250F 2021

Configuration

Map 1 (Default map 1)

Fuel

- Injection main #1
- Injection main speed-density
- Injection crank correction
- Pre-injection

Compensations

Injector 1

Injector 2

- Injector 2 battery correction
- Injector 2 percentage
- Injector 2 phase

Transient

Ignition

Quickshift

Map 2 (Default map 2)

Map 3 (Default map 3)

Map 4 (Default map 4)

Map 5 (Default map 5)

Map 6 (Default map 6)

Expansions

Table

2D

3D

Map 1 - Fuel.Injector 2.Injector 2 phase (Phase (°))

Tps (%)\rpm	500	1000	1500	2000	2500	3000	3500	4000	4500	5000	5500	6000	6500	7000	7500	8000	8500	9000	9500	10000	10500	11000	11500	12000
0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0
2.5	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0
5.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0
10.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0
25.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0
33.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0
50.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0
66.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0
75.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0
100.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0

Depending on the injector operating strategy selected (Configuration -> Parameters -> Strategies -> Injector phase strategy) the entry value in this table is the end or the start angle of the injection phase. This table is made of an X-axis with RPM and Y-axis with TPS.

X-axis = RPM.

Y-axis = TPS.

Entry Point = end or the start angle of the injection phase.

## 8.8.12 – Transient

This function is the one relevant to transient injection mapping tables (transient corrections applied under conditions), these are separated for opening and closing throttle.

**This strategy is deeply explained in Appendix I.**

### 8.8.12.1 – Injection opening transient correction.

GasGas - MC 250F 2021

Configuration

Map 1 (Default map 1)

Fuel

Injection main #1

Injection main speed-density

Injection crank correction

Pre-injection

Compensations

Injector 1

Injector 2

Transient

Injection opening transient correction

Injection closing transient correction

Ignition

Quickshift

Table

2D

3D

Map 1 - Fuel.Transient.Injection opening transient correction

Tps (%)	2.0	3.5	4.5	9.0	15.0	20.0	25.0	30.0	35.0	37.5	40.0	45.0	50.0	55.0	60.0	70.0
Opening speed (%/s)	190	300	320	600	850	950	1050	1100	1150	1200	1250	1300	1350	1400	1450	1520
Correction (%)	13.5	14.5	15.4	17.4	26.3	33.2	35.2	36.1	38.0	39.1	39.3	42.8	44.5	46.2	47.1	49.6
Correction time (r)	4	4	4	4	4	4	4	4	5	5	5	5	5	5	5	5

The table is composed by one X-axis with TPS and three rows of entries: **Opening speed (%/s)**, **Correction (%)** and **Correction period (Rev)**. The strategy works as follows: in dependence upon the throttle position (TPS), if its opening speed (dTPS) is over the corresponding value (in the second-row cell), a correction (in the third-row cell) is applied for a number of revolutions (in the fourth row cell).

### 8.8.12.2 – Injection closing transient correction.

GasGas - MC 250F 2021

Configuration

Map 1 (Default map 1)

Fuel

Injection main #1

Injection main speed-density

Injection crank correction

Pre-injection

Compensations

Injector 1

Injector 2

Transient

Injection opening transient correction

Injection closing transient correction

Ignition

Table

2D

3D

Map 1 - Fuel.Transient.Injection closing transient correction

Tps (%)	20.0	25.0	30.0	32.0	35.0	38.0	43.0	50.0	54.0	57.0	60.0	65.0	70.0	75.0	80.0	85.0
Closing speed (%/s)	-820	-750	-700	-688	-664	-650	-630	-570	-540	-470	-410	-400	-400	-400	-400	-400
Correction (%)	-19.0	-22.0	-27.0	-31.0	-35.0	-46.0	-47.0	-47.0	-48.0	-48.0	-49.0	-51.0	-52.0	-54.0	-51.0	-40.0
Correction time (r)	3	3	3	3	3	3	3	3	3	3	3	1	1	1	2	2

The table is composed by one X-axis with TPS and three rows of entries: **Closing speed (%/s)**, **Correction (%)** and **Correction period (Rev)**. The strategy works as follows: in dependence upon the throttle position (TPS), if its closing speed (dTPS) is below the corresponding value (in the second-row cell), a correction (in the third-row cell) is applied for a number of revolutions (in the fourth row cell).

## 8.9 – Ignition

Ignition
Ignition main #1
Ignition main #2
Ignition main #3
Ignition main #4
Ignition main #5
Ignition main #6
Compensations
Ignition BAP correction
Ignition EWT correction
Ignition IAT correction
Transient
Ignition opening transient correction
Ignition closing transient correction

**Ignition main #1 alpha-n (Advance °)**

GasGas - MC 250F 121

Configuration

Map 1 (Default map 1)\*

Fuel

Ignition

Ignition main #1

Ignition main #2

Ignition main #3

Ignition main #4

Ignition main #5

Ignition main #6

Compensations

Transient

Launch control

Quickshift

Traction control

Map 2 (Default map 2)

Map 3 (Default map 3)

Map 4 (Default map 4)

Map 5 (Default map 5)

Map 6 (Default map 6)

Expansions

Table

2D

3D

Map 1 - Ignition.Ignition main #1 (Advance (°))

Tps (°)/vpm	250	500	750	1000	1250	1500	1750	2000	2250	2500	2750	3000	3250	3500	3750	4000	4250	4500	4750	5000	5250	5500	5750	6000
0.0	9.0	9.0	9.0	9.0	10.4	10.1	10.2	10.5	10.5	10.3	11.0	13.7	17.4	21.7	25.3	30.0	34.3	38.9	41.9	44.8	46.5	47.8	48.4	4
2.5	9.0	9.0	9.0	9.0	10.4	10.1	10.3	10.5	10.5	10.3	11.1	12.7	15.3	19.6	25.2	29.9	34.6	38.8	41.8	44.7	46.4	47.7	48.4	4
5.0	9.0	9.0	9.0	9.0	15.0	14.8	15.0	15.1	15.0	15.5	15.3	17.3	20.0	25.0	28.8	33.3	38.0	40.3	43.0	44.0	45.1	45.9	4	
10.0	9.0	9.0	9.0	9.0	19.7	19.4	19.5	19.7	19.8	19.6	19.7	21.2	23.1	26.1	30.4	34.6	38.0	41.6	43.6	45.4	46.9	48.0	48.7	4
25.0	9.0	9.0	9.0	9.0	11.6	11.3	11.5	11.7	11.7	11.5	10.4	12.0	15.1	18.4	21.7	24.5	26.7	29.8	31.6	33.3	35.1	36.5	37.2	3
33.0	9.0	9.0	9.0	9.0	10.4	10.1	10.3	10.6	10.5	11.1	11.3	11.5	15.9	17.8	19.8	20.9	22.6	24.5	26.6	28.3	30.6	31.4	3	
50.0	9.0	9.0	9.0	9.0	13.2	12.9	13.0	13.2	13.3	13.3	13.8	14.5	17.2	20.0	21.7	22.3	22.4	23.0	23.5	24.0	25.0	25.5	26.1	2
66.0	9.0	9.0	9.0	9.0	13.5	13.3	13.4	13.7	13.6	13.7	13.5	15.8	19.1	22.5	25.6	27.1	27.9	29.4	29.9	30.4	30.6	30.3	30.2	3
75.0	9.0	9.0	9.0	9.0	11.2	11.1	11.2	11.3	11.4	12.1	13.1	16.1	19.4	22.4	25.2	26.9	27.9	29.8	31.0	32.0	32.2	32.1	31.8	3
100.0	9.0	9.0	9.0	9.0	9.1	8.9	9.0	9.1	9.5	10.6	12.3	16.8	20.0	23.1	26.2	29.0	31.4	34.2	34.6	35.4	35.5	35.5	34.5	3

This table is based on RPM (X-axis) and TPS (Y-axis), the entry is the ignition advance in degrees (°). In case of gear dependant setting, this table is used only for the first gear, otherwise is applied for all gears.

**Ignition main #2 alpha-n (Advance °)**

**Ignition main #3 alpha-n (Advance °)**

**Ignition main #4 alpha-n (Advance °)**

**Ignition main #5 alpha-n (Advance °)**

**Ignition main #6 alpha-n (Advance °)**

These tables are applied to the corresponding gear (2 to 6), only if the Map strategy to apply is Gear based.

## **8.10 – Compensations**

### 8.10.1 – Ignition BAP correction (Advance °):

The screenshot shows the 'Map 1 (Default map 1)\*' configuration in the software. The 'Ignition' section is expanded, showing 'Ignition main #1' through '#6' and 'Compensations'. The 'Compensations' section is further expanded, showing 'Ignition BAP correction', 'Ignition EWT correction', and 'Ignition IAT correction'. The 'Ignition BAP correction' is highlighted in blue. To the right, a table titled 'Map 1 - Ignition.Compensations.Ignition BAP correction (Advance (°))' is displayed. The table has columns for 'Advance (°) kPa' and values from 40.0 to 120.0. The row for 'Ignition BAP correction' shows values from 5.0 to 0.0.

Advance (°) kPa	40.0	45.0	50.0	55.0	60.0	65.0	70.0	75.0	80.0	85.0	90.0	95.0	100.0	105.0	110.0	120.0
Ignition BAP correction	5.0	5.0	5.0	5.0	5.0	5.0	5.0	4.0	3.0	2.0	1.0	0.0	0.0	0.0	0.0	0.0

This table represents the Barometric Air Pressure contribution to ignition. This table is based on one X-axis with Barometric pressure and the entries are the angle degrees corrections to apply to the main ignition table.

**This strategy is deeply explained in Appendix H.**

### 8.10.2 – Ignition EWT correction (Advance °)

GasGas - MC 250F 2021		Table 2D 3D	
Configuration			
Map 1 (Default map 1)*			
Fuel			
Ignition			
Ignition main #1			
Ignition main #2			
Ignition main #3			
Ignition main #4			
Ignition main #5			
Ignition main #6			
Compensations			
Ignition BAP correction			
Ignition EWT correction			
Ignition IAT correction			
Transient			

Map 1 - Ignition.Compensations.Ignition EWT correction (Advance (°))																
Advance (°)\°F	-22.0	-4.0	14.0	32.0	50.0	68.0	86.0	104.0	122.0	140.0	158.0	176.0	194.0	212.0	230.0	248.0
	5.0	5.0	5.0	5.0	5.0	4.0	2.0	2.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0

This table represents the Engine Water Temperature (EWT) contribution to ignition. This table is based on one X-axis with EWT and the entries are the offset correction of angle degrees to apply to the main ignition table.

### 8.10.3 – Ignition IAT correction (Advance °)

GasGas - MC 250F 2021		Table 2D 3D	
Configuration			
Map 1 (Default map 1)*			
Fuel			
Ignition			
Ignition main #1			
Ignition main #2			
Ignition main #3			
Ignition main #4			
Ignition main #5			
Ignition main #6			
Compensations			
Ignition BAP correction			
Ignition EWT correction			
Ignition IAT correction			
Transient			
Launch control			

Map 1 - Ignition.Compensations.Ignition IAT correction (Advance (°))																
Advance (°)\°F	-22.0	-4.0	14.0	32.0	50.0	68.0	86.0	104.0	122.0	140.0	158.0	176.0	194.0	194.0	194.0	194.0
	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0


This table represents the Intake Air Temperature (IAT) contribution to ignition.

X-axis = IAT

Entry Points = angle degrees corrections to apply to the main ignition table.

### 8.10.4 – Ignition dwell time (Taipan Y only)

In inductive systems, such as the Yamaha engines managed by the Taipan Y ECU, the Ignition Dwell Time is the time needed to charge the coil as shown in the following image.




'A': the electronic switch opens, and the spark occurs.

'B': the electronic switch closes, and the current grows.

'C': the current reaches its peak.

The period B-A is the "Ignition Dwell Time" to be set in the following table.



### 8.11 – Launch control

**Launch control** is an electronic aid to assist riders to accelerate from a standing start.

This section is viewable only if enabled (click on the map chosen—launch control —enable). You can find the parameters to set the launch control strategy in Configuration -> Parameters -> Launch control.

### 8.11.1 – Injection launch control main table (ms)

[-] GasGas - MC 250F 2021

- [-] Configuration
  - Map 1 (Default map 1)\***
    - [-] Fuel
      - [-] Ignition
        - Ignition main #1
        - Ignition main #2
        - Ignition main #3
        - Ignition main #4
        - Ignition main #5
        - Ignition main #6
      - [-] Compensations
      - [-] Transient
      - [-] Launch control
        - Injection launch control main table**
        - Ignition launch control main table
    - [-] Quickshift
    - [-] Traction control
  - [-] Map 2 (Default map 2)

Table

2D

3D

Map 1 - Launch control.Injection launch control main table (ms)

Tps (°)rpm	250	500	750	1000	1250	1500	1750	2000	2250	2500	2750	3000	3250	3500	3750	4000	4250	4500	4750	5000	5250	5500	5750
0.0	0.760	0.760	0.760	0.760	0.760	0.760	0.760	0.760	0.760	0.760	0.760	0.760	0.760	0.760	0.770	0.740	0.640	0.610	0.560	0.500	0.450	0.420	0.400
2.5	1.180	1.180	1.180	1.180	1.180	1.180	1.180	1.062	1.053	1.044	1.071	1.062	1.053	0.999	0.963	0.945	0.909	0.872	0.761	0.709	0.655	0.615	0.420
5.0	1.380	1.380	1.380	1.380	1.380	1.380	1.380	1.242	1.233	1.233	1.242	1.242	1.224	1.197	1.179	1.159	1.113	1.069	1.014	0.978	0.922	0.877	0.832
10.0	1.840	1.840	1.840	1.840	1.840	1.840	1.840	1.840	1.860	1.940	1.970	1.930	1.850	1.720	1.640	1.550	1.490	1.440	1.410	1.380	1.360	1.330	1.290
25.0	3.020	3.020	3.020	3.020	3.020	3.020	3.010	2.990	3.020	3.210	3.350	3.360	3.180	2.960	2.810	2.700	2.630	2.580	2.530	2.490	2.450	2.380	2.350
33.0	3.510	3.510	3.510	3.510	3.510	3.510	3.480	3.440	3.470	3.560	3.570	3.610	3.490	3.120	3.030	2.990	2.950	2.910	2.900	2.890	2.880	2.880	2.900
50.0	3.660	3.660	3.660	3.660	3.660	3.660	3.620	3.580	3.620	3.760	3.790	3.840	3.610	3.260	3.090	3.060	3.050	3.030	3.070	3.120	3.220	3.330	3.450
66.0	3.750	3.750	3.750	3.750	3.750	3.750	3.710	3.670	3.720	3.880	4.000	3.970	3.670	3.380	3.150	3.100	3.100	3.110	3.130	3.150	3.270	3.390	3.530
75.0	3.650	3.650	3.650	3.650	3.650	3.650	3.420	3.380	3.430	3.570	3.640	3.610	3.340	3.150	3.100	2.930	2.930	2.930	2.980	3.020	3.150	3.270	3.400
100.0	3.570	3.570	3.570	3.570	3.380	3.260	3.230	3.150	3.230	3.380	3.410	3.390	3.210	3.010	2.860	2.720	2.700	2.680	2.680	2.700	2.860	3.030	3.030

If the Launch control strategy is enabled (Map n -> Launch control -> Enabled) and the corresponding conditions (in Configuration-> Parameters->Launch control) met and a proper switch (like the AiM Handlebar switch or the stock launch control switch if is present on the bike) is present on the motorbike (and the activation button is pressed) this table is applied. This is based on TPS (Y axis) and Rpm (X axis), the entry is the injection time in ms.

### 8.11.2 – Ignition launch control main table (Advance (°))

GasGas - MC 250F 2021

Configuration

Map 1 (Default map 1)\*

Fuel

Ignition

Ignition main #1

Ignition main #2

Ignition main #3

Ignition main #4

Ignition main #5

Ignition main #6

Compensations

Transient

Launch control

Injection launch control main table

Ignition launch control main table

Quickshift

Traction control

Map 2 (Default map 2)

Map 3 (Default map 3)

Table

2D

3D

Map 1 - Launch control.Ignition launch control main table (Advance (\*))

Tps (%)/rpm	250	500	750	1000	1250	1500	1750	2000	2250	2500	2750	3000	3250	3500	3750	4000	4250	4500	4750	5000	5250	5500	5750	6000
0.0	9.0	9.0	9.0	9.0	10.4	10.1	10.2	10.5	10.5	10.3	11.0	13.7	17.4	21.7	25.3	30.0	34.3	38.9	41.9	44.8	46.5	47.8	48.4	48.4
2.5	9.0	9.0	9.0	9.0	10.4	10.1	10.3	10.5	10.5	10.3	11.1	12.7	15.3	19.6	25.2	29.9	34.6	38.8	41.8	44.7	46.4	47.7	48.4	48.4
5.0	9.0	9.0	9.0	9.0	15.0	14.8	15.0	15.1	15.0	15.1	15.5	15.3	17.3	20.0	25.0	28.8	33.3	38.0	40.3	43.0	44.0	45.1	45.9	46.4
10.0	9.0	9.0	9.0	9.0	19.7	19.4	19.5	19.7	19.8	19.6	19.7	21.2	23.1	26.1	30.4	34.6	38.0	41.6	43.6	45.4	46.9	48.0	48.7	49.0
25.0	9.0	9.0	9.0	9.0	11.6	11.3	11.5	11.7	11.7	11.5	10.4	12.0	15.1	18.4	21.7	24.5	26.7	29.8	31.6	33.3	35.1	36.5	37.2	37.3
33.0	9.0	9.0	9.0	9.0	10.4	10.1	10.3	10.6	10.5	10.3	10.3	11.1	13.5	15.9	17.8	19.8	20.9	22.6	24.5	26.6	28.3	30.6	31.4	31.4
50.0	9.0	9.0	9.0	9.0	13.2	12.9	13.0	13.2	13.3	13.3	13.8	14.5	17.2	20.0	21.7	22.3	22.4	23.0	23.5	24.0	25.0	25.5	26.1	26.1
66.0	9.0	9.0	9.0	9.0	13.5	13.3	13.4	13.7	13.6	13.7	13.5	15.8	19.1	22.5	25.6	27.1	27.9	29.4	29.9	30.4	30.6	30.3	30.2	30.3
75.0	9.0	9.0	9.0	9.0	11.2	11.1	11.2	11.3	11.4	12.1	13.1	16.1	19.4	22.4	25.2	26.9	27.9	29.8	31.0	32.0	32.2	32.1	31.8	31.8
100.0	9.0	9.0	9.0	9.0	9.1	8.9	9.0	9.1	9.5	10.6	12.3	16.8	20.0	23.1	26.2	29.0	31.4	34.2	34.6	35.4	35.5	35.5	34.5	34.3

If the Launch control strategy is enabled (Map n -> Launch control -> Enabled), the corresponding conditions (in Configuration -> Parameters -> Launch control) are met and a proper switch (like the AiM Handlebar switch or the stock launch control switch if is present on the bike) is present on the motorcycle this table is applied. This table is based on TPS (Y axis) and Rpm (X axis) and the entry is the offset correction of angle degrees.

### 8.12 – Quick shift

Quick shift is a strategy that works by reducing time of power loss between gear changes.

This section is viewable only if enabled (click on Configuration -> Strategies -> Quick shift -> Enable). You can find the parameters to set the Quick shift strategy in Configuration -> Parameters -> Strategies -> Quick shift.

### 8.12.1 – Quick shift cut timetable (ms)

GasGas - MC 250F 2021

Configuration

Parameters

CAN configuration

Sensors

Map 1 (Default map 1)\*

Fuel

Ignition

Launch control

Quickshift

Quickshift cut time table

Traction control

Map 2 (Default map 2)

Map 3 (Default map 3)

Map 4 (Default map 4)

Map 5 (Default map 5)

Map 6 (Default map 6)

Expansions

Table

2D

3D

Map 1 - Quickshift.Quickshift cut time table (ms)

Tps (%)\rpm	500	1000	1500	2000	2500	3000	3500	4000	4500	5000	5500	6000	6500	7000	7500	8000	8500	9000	9500	10000
0.0	25.000	25.000	25.000	25.000	25.000	25.000	25.000	25.000	25.000	25.000	25.000	25.000	25.000	25.000	25.000	25.000	25.000	25.000	25.000	25.000
2.5	25.000	25.000	25.000	25.000	25.000	25.000	25.000	25.000	25.000	25.000	25.000	25.000	25.000	25.000	25.000	25.000	25.000	25.000	25.000	25.000
5.0	25.000	25.000	25.000	25.000	25.000	25.000	25.000	25.000	25.000	25.000	25.000	25.000	25.000	25.000	25.000	25.000	25.000	25.000	25.000	25.000
10.0	25.000	25.000	25.000	25.000	25.000	25.000	25.000	25.000	25.000	25.000	25.000	25.000	25.000	25.000	25.000	25.000	25.000	25.000	25.000	25.000
25.0	25.000	25.000	25.000	25.000	25.000	25.000	25.000	25.000	25.000	25.000	25.000	25.000	25.000	25.000	25.000	25.000	25.000	25.000	25.000	25.000
33.0	25.000	25.000	25.000	25.000	25.000	25.000	25.000	25.000	25.000	25.000	25.000	25.000	25.000	25.000	25.000	25.000	25.000	25.000	25.000	25.000
50.0	25.000	25.000	25.000	25.000	25.000	25.000	25.000	25.000	25.000	25.000	25.000	25.000	25.000	25.000	25.000	25.000	25.000	25.000	25.000	25.000
66.0	25.000	25.000	25.000	25.000	25.000	25.000	25.000	25.000	25.000	25.000	25.000	25.000	25.000	25.000	25.000	25.000	25.000	25.000	25.000	25.000
75.0	25.000	25.000	25.000	25.000	25.000	25.000	25.000	25.000	25.000	25.000	25.000	25.000	25.000	25.000	25.000	25.000	25.000	25.000	25.000	25.000
100.0	25.000	25.000	25.000	25.000	25.000	25.000	25.000	25.000	25.000	25.000	25.000	25.000	25.000	25.000	25.000	25.000	25.000	25.000	25.000	25.000

If the Quick shift strategy is enabled (Configuration -> Parameters -> Strategies -> Quick shift) and the corresponding conditions are met, this table is applied.

X Axis = RPM

Y Axis = TPS

Entry points = cut times in ms, used during gear shifts.

### 8.13 – Traction control

GasGas - MC 250F 2021

Configuration

Parameters

CAN configuration

Sensors

Map 1 (Default map 1)\*

Fuel

Ignition

Launch control

Quickshift

Traction control

Traction control

Map 2 (Default map 2)

Map 3 (Default map 3)

Map 4 (Default map 4)

Map 5 (Default map 5)

Map 6 (Default map 6)

Expansions

Table

2D

3D

Map 1 - Traction control.Traction control

Tps (%)	0.0	2.5	5.0	8.0	10.0	12.0	15.0	20.0	25.0	30.0	40.0	50.0	60.0	70.0	80.0	90.0
rpm/s	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0
Ignition advance offset (°)	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0
Injection phase offset advance (°)	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0
Correction maintenance (r)	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0

**Traction control** is a system that stops the wheels of a vehicle from spinning when excess power is applied.

If the traction control strategy is enabled (Map -> Traction control -> Enable) and the corresponding conditions are met, this table is applied.

This is based on TPS (X axis) and four rows of entries:

- **Traction Control Factor (Rpm/s)**
- **Ignition advance offset (Advance (°)),**
- **Injection phase offset (Advance (°))**
- **Correction maintenance (Rev).**



### 8.13.1 – Traction control strategy

The traction control strategy has been designed in order to control the slipping of the rear wheel of the vehicle. A slipping wheel condition is necessarily transmitted to a sudden increase of the engine Rpm and therefore to a peak of engine acceleration. Therefore, our control strategy is based on monitoring the engine acceleration through a constant that from now on we will call “Traction Control factor” expressed in Rpm/s.

The Tc factor has been used as threshold to activate or not the corrections of the traction control. In other words, it means that, if the ECU detects a Tc factor higher than the one set in the Traction control table, the corrections are activated.

An example of an empty Traction control table is shown below:

Map 1 - Traction control.Traction control																
Tps (%)	0.0	2.5	5.0	8.0	10.0	12.0	15.0	20.0	25.0	30.0	40.0	50.0	60.0	70.0	80.0	90.0
rpm/s	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0
Ignition advance offset (°)	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0
Injection phase offset advance (°)	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0
Correction maintenance (r)	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0

Afterwards, since the traction corrections should provide less power to the vehicle, the rear wheel of the vehicle should regain grip and the engine acceleration should decrease as the Tc factor. By doing so, the ECU will continue to use the traction corrections until the Tc factor computed goes below the Tc factor threshold set in the Traction control table (first raw of the table).

At this point the previous corrections are maintained for a number of engine revolutions as set in the last raw of the Traction control table called “Correction maintenance(r)” (figure below).

Map 1 - Traction control.Traction control																
Tps (%)	0.0	2.5	5.0	8.0	10.0	12.0	15.0	20.0	25.0	30.0	40.0	50.0	60.0	70.0	80.0	90.0
rpm/s	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0
Ignition advance offset (°)	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0
Injection phase offset advance (°)	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0
Correction maintenance (r)	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0

Keep in mind that, a part of the engine revolutions set in the correction maintenance is used by the strategy to return linearly to the 0-correction condition.

This has been used in order to have a transition between active and non-active correction condition as smooth as possible.

The Traction control corrections editable in Spark software are:

- The “Ignition advance offset (°)” that is an offset correction expressed in degrees for the Ignition advance, more into detail, for instance, if the value of this correction is -5° it means that the ECU is shifting forward the value of the main ignition advance table by a value of 5°, thus having a delay in the ignition advance.
- The “Injection phase offset advance (°)” that is an offset correction expressed in degrees for the injection phase advance, so, for instance, if the value of this correction is -35° it means that the ECU is shifting forward the value of the injector 1 phase table, thus having a delay in the injector phase.

Keep in mind that, if the vehicle has a second injector the traction control injection phase correction is acting on the main injector (Injector 1).



### 8.13.2 – Activate the traction control strategy

In order to activate the Traction control strategy, it is necessary to do a few mandatory things:

- Select “enabled” on the traction control strategy flag, corresponding to the map desired as shown below

- Write to the ECU a map with a non-empty traction control table
- Activate the Traction control using the AiM HBS switch or using the standard button of the motorbike if provided by the manufacturer

Consider that if you are using the AiM HBS there are 5 levels of traction control selectable: with 1 being the minimum and 5 being the maximum.

It means that level 5 of Traction control corresponds to the corrections set in the Traction control table of the corresponding map.

Therefore, the other TC levels are a percentage of the Traction correction table that corresponds to the maximum, more into details:

- Level 5 – 100% Tc corrections
- Level 4 – 80% Tc corrections
- Level 3 – 60% Tc corrections
- Level 2 – 40% Tc corrections
- Level 1 – 20% Tc corrections

Please note that the Traction Control must be enabled for the selected Map: this will be done during the ECU Map configuration.

To give a reference, it is shown below the Traction control table we provide for the motorcycle model Husqvarna – FE 350 2022.

	2D	3D
Husqvarna - FE 350 2022		
Configuration		
Map 1 (Top Performance)		
Fuel		
Ignition		
Launch control		
Quickshift		
Traction control		
Traction control		
Map 2 (Linear)		
Map 3 (RPM Optimizer)		

Map 1 - Traction control.Traction control																
Tps (%)	18.0	20.0	25.0	30.0	35.0	40.0	45.0	50.0	55.0	60.0	65.0	70.0	75.0	80.0	85.0	90.0
rpm/s	10000	1000	1500	3000	3250	3500	3750	4000	4250	4500	4750	5000	5250	5500	5750	6000
Ignition advance offset (°)	0.0	-6.0	-8.0	-10.0	-10.0	-10.0	-10.0	-10.0	-10.0	-10.0	-11.0	-11.0	-12.0	-12.0	-12.0	-12.0
Injection phase offset advance (°)	0.0	-35.0	-35.0	-45.0	-45.0	-45.0	-45.0	-45.0	-45.0	-45.0	-45.0	-50.0	-50.0	-50.0	-50.0	-50.0
Correction maintenance (fr)	20	20	20	15	15	15	15	15	15	15	15	10	10	10	10	10


Before using the traction control strategy, make sure to have updated the firmware of the Taipan ECU.

## 8.14 – Expansions



This section is made to enable the Handlebar switch.

## 9 – Data view – special key and visualization



The data view area can show the mapping tables in three different ways:

- Table Format
- 2D Format
- 3D Format (will be available soon)

It is possible to switch this view by pushing the tab placed on top of the data view area or using the shortcut:  
- Ctrl button plus 1, 2 or 3 (1 for table view, 2 for 2D view and 3 for the 3D view).

### 9.1 - Table Format

This mode allows to type in the entry values in the cells, modify them and the breakpoints. The entries can be modified one by one, or grouped together, selecting. The selection on the table can be done with **shift + arrow** keys or using a mouse.

To select a group of entries:


- Left click and press for desired table zone (mouse)
- Shift + Arrows move for desired zone (keyboard)

Once elements (entries) are selected, it is possible to change their value in the following ways:

#### Mouse

- Right click (mouse) a pop-up is prompted to type the desired change.
  - o Add -> algebraic addition of a defined quantity to the selected entry(s)
  - o Add% -> percentual addition of a defined quantity to the selected entry(s)

- Set -> forcing the desired value to the selected entry(s)




## Keyboard

- Ctrl+Up -> Increment the selected entries for entry resolution x 10.
- Ctrl+Down -> Decrement the selected entries for entry resolution x 10.
- Alt+Up -> Increment the selected entries for entry resolution.
- Alt+Down -> Decrement the selected entries for entry resolution.
- Type in the value -> Force all entries to the desired number.

Once data have been changed, modified cells are highlighted in orange to show that the data is changed but not yet sent to the ECU. To send it to the ECU push enter on the keyboard, and the cells transmitted to the ECU are highlighted in green, to show that they have been written in temporary way. They have not been flashed into the ECU for permanent use.

To write the whole table directly into the ECU it is possible to select it clicking on the top left section. Then (with ECU connected and project opened) clicking the right button of the mouse on the map selected (left menu) you can directly write the whole table into the ECU.



Shortcuts for these tasks are available:

- Alt-Shift-T, to write the whole table.
- Alt-T, to read the whole table.

## **9.2 - 2D Format**

To select the 2D graphs is possible:

Direct mouse selection (mouse)

- Once the mouse focus is on this window (click) move among graphs with the arrow keys (keyboard)

Graphs can be modified point-by-point, after having selected the desired point:

### **Mouse**

- Holding pressed the right button and dragging the line.

### **Keyboard**

- Ctrl+Up -> Increment the selected entries for entry resolution (+ 0,1 per pressure)
- Ctrl+Down -> Decrement the selected entries for entry resolution (+ 0,1 per pressure)
- Alt+Up -> Increment the selected entries for entry resolution.
- Alt+Down -> Decrement the selected entries for entry resolution.

Once data have been changed in the 2D graph, to write them into the ECU return in the Table view and press the Enter Key.

In the Table view, breakpoints can be locked not to change them unintentionally. This is done ticking the flag at the right bottom corner of the Data view area.

☐ Lock breakpoints

To focus on a particular line, you can click on the line and press the shortcut Ctrl-Q. This hides the other lines. Use Ctrl-W to make them reappear.

## **9.3 – 3D Format**

This feature will be uploaded soon. A proper function explanation will be prepared at that time.

## **10 – Live Measures view box**

INJ1 time	--	ECT	--	IGN	--	Sync err	--
INJ1 phase	--	IAT	--	INJ base	--	Eng pos	--
INJ2 time	--	V ign	--	RPM	--	Eng state	--
INJ2 phase	--	λ	--	TPS	--	Eng revs	--

This area is used to monitor live data. Available parameters change according to the licence in use. This is activated only when the ECU is connected. Can be hidden/shown pressing the hide/show Live Measures panel button in the icon bar. Hiding this panel is recommended when the Data view area must be maximized.

Only if Live Measures is activated, live faults can be shown by the diagnostics section.

### Live Measures parameters:

INJ1 time: Total injector1 time of injection

INJ1 phase: Injector 1 phase of injection

INJ2 time: Total injector2 time of injection

INJ2 phase: Injector 2 phase of injection

ECT: Engine coolant temperature

IAT: Intake air temperature

V ign: Motorcycle ignition voltage

$\lambda$ : Lambda values (if ECU connected to an AiM logger that has LCU1 controller)

IGN: Ignition advance

INJ base: Injection base time from main table

RPM: RPM at the moment

TPS: Throttle position percentage at the moment


Sync err: Synchronism errors

Eng pos: Engine position, divided in Seek, Semi phased and Phased

Eng state: Engine state divided in stop, cranking and running.

Eng revs: Engine revolutions number

## 11 – Info bar



The bottom Info bar is a quick monitor for the ECU and software communication state.



There are the following fields.

- Semaphore
  - red light: the ECU is not recognized.
  - orange blinking light: ECU is being recognized.
  - green: the ECU is recognized.
- Ecu status (not connected or firmware, it depends on whether the control unit is connected. If the ecu is not connected you cannot write or flash anything in the ECU).
- Project (project locked by password or not).
- ECU (ECU target locked by password or not).
- Running map number
- Live Measures status (active – not active).
- Operation progress percentage
- Status bar showing the operation progress of a process (opposite corner in the bottom Info bar)

## **Appendix A – Taipan/Taipan Y ECU Part Numbers**


XE1UCBT00	UC BRIDGE TUNER
XE1UCB000	UC BRIDGE
XE1HBS000	HBS
XE1ECUCB0	ECU TAIPAN
XE1ECUCB1	ECU TAIPAN Y
XE1ECUHBSUCB0	ECU + HBS + UC BRIDGE
XE1ECUHBS00	ECU + HBS

**Appendix B – ECU Taipan/Taipan Y dimensions and pinout**



JST 04T-JWPF-VSLE-S CONNECTOR EXT VIEW	JST 08R-JWPF-VSLE-D CONNECTOR EXT VIEW	JST 04R-JWPF-VSLE-S CONNECTOR EXT VIEW
1 - GND 2 - CAN CAL HIGH 3 - CAN CAL LOW 4 - 12V IN	1 - 12V SECOND INJ 2 - LOW SIDE SECOND INJ 3 - LOW SIDE 4 - GND 5 - ANALOG INPUT 1 6 - ANALOG INPUT 2 7 - DNC 8 - DNC	1 - GND 2 - CAN EXP HIGH 3 - CAN EXP LOW 4 - 12V OUT (switched)

Appendix C – Harness CAN + Ext power for Solo2 DL





## Appendix D – Main terms

Here, a list of terms used in this document and relevant to the Spark software.

**Configuration:** A Configuration includes the base parameters not directly related to the engine performance. i.e.:

- Set up the second injector if present.
- Set up range of sensor plausibility.
- Set up parameters for the map switch like fuel correction, threshold of RPM to activate the correction chosen.
- Enable/disable launch control.
- Enable/disable pre injection.
- Set up the RPM limiters.
- Set up strategies (The drop sensor, injection, injector phase strategy, neutral strategy, quick shift).
- Set up the VB out (Voltage Battery Output).
- Set up the Can configuration.
- Set up sensors.

**Table:** The main feature of a table is the presences of one or two breakpoint axis dependent from the type of table (2D: One breakpoint axis, 3D: two breakpoint axis). The table is composed by cells that are a correlation between variables. Here below an example of table.

Map 1 - Fuel Injection main #1 (ms)																																				
Tps (°/vpm)	250	500	750	1000	1250	1500	1750	2000	2250	2500	2750	3000	3250	3500	3750	4000	4250	4500	4750	5000	5250	5500	5750	6000	6250	6500	6750	7000	7250	7500	7750	8000	8250	8500	8750	9000
0.0	0.760	0.760	0.760	0.760	0.760	0.760	0.760	0.760	0.760	0.760	0.760	0.760	0.760	0.760	0.760	0.770	0.740	0.640	0.610	0.560	0.500	0.450	0.420	0.380	0.333	0.314	0.285	0.285	0.285	0.285	0.285	0.285	0.285	0.285	0.285	0.271
2.5	1.180	1.180	1.180	1.180	1.180	1.180	1.180	1.062	1.053	1.044	1.071	1.062	1.053	0.999	0.963	0.945	0.909	0.872	0.828	0.761	0.709	0.655	0.619	0.573	0.546	0.513	0.496	0.453	0.445	0.419	0.403	0.385	0.368	0.343	0.350	0.340
5.0	1.380	1.380	1.380	1.380	1.380	1.380	1.380	1.242	1.233	1.233	1.242	1.242	1.224	1.197	1.179	1.159	1.113	1.069	1.014	0.978	0.922	0.877	0.832	0.795	0.778	0.752	0.718	0.674	0.648	0.638	0.614	0.599	0.571	0.555	0.550	0.550
10.0	1.840	1.840	1.840	1.840	1.840	1.840	1.840	1.840	1.860	1.940	1.970	1.930	1.850	1.720	1.640	1.550	1.490	1.440	1.410	1.380	1.360	1.330	1.290	1.250	1.231	1.202	1.173	1.144	1.116	1.080	1.063	1.036	1.018	1.014	1.000	0.990
25.0	3.020	3.020	3.020	3.020	3.020	3.020	3.010	2.990	3.020	3.210	3.350	3.360	3.180	2.960	2.810	2.700	2.630	2.580	2.530	2.490	2.450	2.380	2.350	2.296	2.247	2.228	2.218	2.209	2.200	2.162	2.143	2.124	2.106	2.087	2.080	2.060
33.0	3.510	3.510	3.510	3.510	3.510	3.510	3.480	3.440	3.470	3.560	3.570	3.610	3.490	3.120	3.030	2.990	2.950	2.910	2.900	2.890	2.880	2.880	2.900	2.910	2.920	2.920	2.910	2.900	2.880	2.840	2.760	2.679	2.632	2.594	2.537	2.480
50.0	3.660	3.660	3.660	3.660	3.660	3.660	3.620	3.580	3.620	3.760	3.790	3.840	3.610	3.260	3.090	3.060	3.050	3.030	3.070	3.120	3.220	3.330	3.450	3.580	3.680	3.780	3.830	3.880	3.890	3.900	3.880	3.850	3.800	3.740	3.640	3.540
66.0	3.750	3.750	3.750	3.750	3.750	3.750	3.710	3.670	3.720	3.880	4.000	3.970	3.670	3.350	3.150	3.100	3.100	3.110	3.130	3.150	3.270	3.390	3.530	3.670	3.810	3.960	4.060	4.000	4.220	4.280	4.320	4.340	4.330	4.320	4.250	4.190
75.0	3.650	3.650	3.650	3.650	3.570	3.460	3.420	3.380	3.430	3.570	3.640	3.610	3.340	3.180	3.010	2.930	2.930	2.980	3.020	3.150	3.270	3.400	3.530	3.620	3.770	3.880	4.000	4.050	4.170	4.220	4.270	4.270	4.250	4.240		
100.0	3.570	3.570	3.570	3.570	3.380	3.260	3.230	3.150	3.230	3.380	3.410	3.390	3.210	3.010	2.860	2.720	2.700	2.680	2.680	2.700	2.860	3.030	3.030	3.180	3.260	3.400	3.540	3.680	3.780	3.890	4.060	4.150	4.200	4.250	4.260	4.280

**Map:** A Map is the combination of all the parameters governed by the ECU directly related to engine performance and consist of different tables. The main maps are the fuel and ignition, but you can also set up the tables of various strategies and sensors, as we see in the next chapters.

**Project:** A project is the union of ECU configuration and ECU Maps.

**Breakpoint:** A breakpoint is the segmentation of the axis. Breakpoints can be equally distributed or increased in specific areas where more accuracy is desired. The trend of breakpoints is monotone.

**Entry:** An entry is the desired value that the user wants to set in a specific cell in the table.

**Engine hour meter:** The engine hour meter is the time the engine has been used with this ECU.

**Write:** means that the data is sent real time to the ECU, but it is not stored in the ECU. As soon as this is turned off, data “written” are cleared. Generally used to tune some entries live.

**Flash:** means that the data is sent real time to the ECU and it is stored in a permanent memory. Generally used to write a complete map.

**TPS:** Throttle Position Sensor in %.

**ECT:** Engine Coolant Temperature.

**MAP:** Manifold Air Pressure.

**Baro:** Barometric Air Pressure.

**EWT:** Engine Water Temperature.

**IAT:** Intake Air Temperature.

**VIGN:** Ignition Voltage in V.

**Project File:** It is the combination of configuration and all the maps.

**Valid Map:** A map may be not valid in these situations:

- if it is not completely transmitted to the ECU.
- it is not compatible with the firmware version of the ECU.

**Running Map:** A Running Map is the map actually used by the ECU.

## Appendix E – Pre-injection

Pre-injection is intended to avoid starting problems, which could happen in some situations:


- When the water or coolant temperature is low.
- When the geometry of the ducts is not very straight in the direction of the intake valve.
- When the position of the injector is not in line with the intake valve.

The basic purpose of this strategy is to activate, at the beginning of the crank phase, a disposable injection, which goes to wet the intake duct. This allows the subsequent injections not to settle on the ducts, to facilitate starting the motorcycle.

Looking at the image here down:


- Light blue: flywheel signal
- Green: injector command (injects when piloted low)

As can be seen, this strategy, if enabled, intervenes when the ECU is powered at the first rotation of the flywheel to the first tooth detected, regardless of the position of the piston.



In the red circle, the pre-injection time is highlighted.

This strategy is enabled within the configuration of the project file, in:  
Configurations->Parameters->Pre-Injection



For every map, a pre-injection table is available:

Ms\°C	-15	-3	0	9	14	20	24	34	39	66	82	99
	22	13	9	7	5	4	4	4	3	2	2	2

where the X-axis shows the water temperature, and the entry points are the pre-injection times in msec. The table above, to be considered as an example, was obtained on an experimental basis, verifying, at the different temperatures at the start-up, how the pre-injection affects the start-up itself. It is easy to see how the pre-injection is more important at low temperatures.

## Appendix F – Injection crank correction (%)

The crank injection correction intervenes to facilitate engine starting, when an extra amount of fuel is required than is necessary to keep the engine running in normal conditions. To define this correction, the following table is available:

Table

2D

3D

Map 1 - Fuel Injection crank correction (%)

°Cv	0	1	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16	18	120	300
-40.0	152.0	155.0	158.0	159.0	159.0	158.5	157.8	154.9	150.8	145.7	140.9	137.7	137.7	137.5	137.5	137.5	137.5	141.5	145.5	145.5
-30.0	142.0	145.0	148.0	149.0	149.0	148.5	147.8	144.9	140.8	135.7	130.9	127.7	127.7	127.5	127.5	127.5	127.5	131.5	135.5	135.5
-20.0	132.0	135.0	138.0	139.0	139.0	138.5	137.8	134.9	130.8	125.7	120.9	117.7	117.7	117.5	117.5	117.5	117.5	121.5	125.5	125.5
-10.0	122.0	125.0	128.0	129.0	129.0	128.5	127.8	124.9	120.8	115.7	110.9	107.7	107.7	107.5	107.5	107.5	107.5	111.5	115.5	115.5
0.0	109.0	113.0	117.0	119.0	120.0	119.5	117.8	114.9	109.8	103.7	95.9	89.7	88.7	88.5	88.5	88.5	89.5	96.5	102.5	102.5
10.0	97.0	101.0	105.0	108.0	110.0	109.5	108.8	104.9	99.8	91.7	84.9	78.7	75.7	74.5	74.5	74.5	76.5	82.5	88.5	88.5
20.0	82.0	87.0	92.0	95.0	97.0	97.5	95.8	92.9	86.8	78.7	69.9	64.7	63.7	63.5	63.5	63.5	64.5	67.5	69.5	69.5
30.0	53.0	59.0	63.0	66.0	67.0	66.5	63.8	59.9	55.8	50.7	45.9	40.7	35.7	33.5	32.5	32.5	32.5	33.5	38.5	45.0
40.0	26.0	28.0	30.0	31.0	31.0	33.0	38.0	42.0	45.0	46.0	43.0	38.0	25.0	15.0	15.0	15.0	15.0	17.0	23.0	30.0
50.0	22.0	24.0	27.0	27.0	26.0	27.0	33.0	39.0	43.0	44.0	43.0	38.0	25.0	15.0	15.0	15.0	15.0	15.0	15.0	30.0
55.0	22.0	24.0	27.0	27.0	26.0	27.0	33.0	39.0	43.0	44.0	43.0	38.0	25.0	15.0	15.0	15.0	15.0	15.0	15.0	0.0
60.0	20.0	21.0	23.0	24.0	22.0	22.0	28.0	34.0	38.0	39.0	38.0	33.0	25.0	15.0	15.0	15.0	15.0	15.0	15.0	0.0
65.0	20.0	21.0	23.0	24.0	22.0	22.0	28.0	34.0	38.0	39.0	38.0	33.0	25.0	15.0	15.0	15.0	15.0	15.0	15.0	0.0
70.0	10.0	9.0	12.5	10.5	10.5	11.0	14.0	17.0	19.0	19.5	19.0	16.5	12.5	7.5	7.5	7.5	7.5	7.5	7.5	0.0
75.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0
80.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0
85.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0
90.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0
95.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0
150.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0

This table is defined by:

- X axis: number of motor revolutions
- Y axis: engine coolant temperature
- Entry Points: injection time correction percentage

As stated, this strategy works for a limited number of revolutions, as defined in the last value of the X-Axis.

So, once the Start Button is pushed, the injection time will be calculated considering all the following tables:

- the main table "Main table" indicating the injection time,
- the injector battery compensation,
- compensation of the air temperature
- compensation of the barometric pressure
- **the contribution deriving from the crank injection time correction table.**

Let us imagine scrolling this table from left to right at start-up: once the revolutions indicated as the last point on the X axis are finished, the crank phase can be considered finished, and the crank injection correction is interrupted. At this point, the Injection Time Compensation Table will intervene based on the temperature of the coolant.

So, in the example of the table above, once the 300 revolutions of the engine have been exceeded, the following contributions will intervene:

- the “main” table indicating the injection time
- the injector battery compensation
- compensation of the air temperature
- compensation of the barometric pressure
- **the contribution deriving from the interpolation of the injection time compensation table as a function of the temperature of the coolant.**

The graph below shows an example of strategy intervention and management:

pink: water temperature


green: number of motor revolutions

blue: correction contribution to the crank


red: water temperature correction contribution

white: lambda probe value

orange: RPM



In this example, in the very first revolutions managed by the starter, there is a correction contribution to the crank of 20%. The lambda value will show the effect of the crank - correction a few revolutions after the implementation as shown below.




In the picture here above, you may note the crank injection correction peak and the effect of this correction on the lambda level.


The lambda value at this stage is very important:

- if too low "the engine drowns" (too much gasoline) and it will not start, with the risk of wetting the spark plug
- if it is too high, the gasoline will not be enough to start the engine.

After the crank, the engine is at idle, and the lambda value will stabilize at the desired target value, as shown in the image below.



The last image shows exactly when the correction of the injection to the crank stops, and the correction is managed in accordance with the coolant temperature.





## Appendix G – Injection N battery correction

One of the most important parameters for the engine control is the injection time, i.e., the duration of the injector command pulse so that the desired amount of petrol enters the combustion chamber of the engine. The injection time is calculated based on parameters, some of which depend on the characteristics of the injector, while others depend on other factors, such as water temperature, air, barometric pressure, etc.

Here we see how the injector power supply voltage affects the opening time of the injector during the injection. The injector can be schematized as in this image:



This is a very simple circuit consisting of an inductor and a resistor. The inductive component, depending on the applied voltage, will make the injector open more or less quickly.

Injector manufacturers always provide a table such as this one below, which represents the characterization of the injector itself. The table is very simple:

### G2-99-0123

350 CC/MIN - 32 LBS/HR

EV6/EV14/USCAR electrical connector



Fuel Pressure		Voltage Offset					Flow Rate	
PSID	BAR	8 Volts	10 Volts	12 Volts	14 Volts	16 Volts	cc/min	lbs/hr
43.5	3.00	1.890	1.530	1.120	0.750	0.490	309	29
45	3.10	1.935	1.518	1.095	0.733	0.485	321	31
50	3.44	1.980	1.505	1.070	0.715	0.480	334	32
55	3.79	2.025	1.492	1.045	0.697	0.475	346	33
60	4.13	2.070	1.480	1.020	0.680	0.470	358	34
65	4.48	2.190	1.555	1.060	0.710	0.500	371	35
70	4.82	2.310	1.630	1.110	0.740	0.530	383	36
75	5.17	2.370	1.675	1.135	0.765	0.550	396	38
80	5.51	2.430	1.720	1.170	0.790	0.570	408	39
85	5.86	2.485	1.765	1.210	0.820	0.595	420	40
90	6.20	2.540	1.810	1.250	0.850	0.620	433	41
95	6.55	2.600	1.855	1.280	0.875	0.635	449	43
100	6.89	2.660	1.900	1.310	0.900	0.650	464	44

Voltage offset values are in milliseconds ms - 1ms = 1000us



STANDARD

At a certain fuel pressure (column 1/2) to obtain the desired amount of fuel (column 8/9), the injector must remain open for the time in msec depending on the power supply voltage indicated in the various "Voltage Offset" columns (columns 3/7).

The overall injection time driven by the ECU will therefore be given by considering, in addition to the set of contributions on the main table, also from this "offset" strictly dependent on the intrinsic characteristics of the injector.



## **Appendix H – Injection BAP correction**

- BAP means Barometric Air Pressure, the weight exerted on the Earth by the air present in the atmosphere. The barometric pressure is therefore the pressure exerted at a certain point by the column of air that goes from the highest point of the atmosphere to the ground. It is obvious that the higher you move, the lower is the barometric pressure value.
- AFR means Air Fuel Ratio, that is the ratio between the intake air and the injected gasoline.

On a beautiful day at sea level the barometric pressure is 1020mBar, and a motorcycle at idle speed will have an AFR of 0.89. If you go up to 2500 m (8000 ft), where the air pressure is 780mBar, how will the lambda change? Given the premises described above, and knowing that as the height increases, the weight of the air column decreases, there is less air at altitude and therefore the AFR ratio decreases. If in these conditions we left the injected petrol unchanged, our engine would get greased, with even the risk of being shut down due to too much injected petrol.

Injection BAP correction serves to avoid this effect and acts by decreasing the percentage of petrol injected as the barometric pressure decreases in order to maintain the target lambda value.

This compensation table is very simple and is shown below:

%\mbar	400	450	500	550	600	650	700	750	800	850	900	950	1000	1050	1100	1200
	-50.0	-50.0	-50.0	-45.0	-40.0	-37.0	-32.0	-27.0	-22.0	-17.0	-5.0	0.0	0.0	0.0	5.0	10.0

The pressure value in mBar is shown on the X axis, and the percentage correction on injected petrol as an entry point value.

## Appendix I – Transient management

Managing transient throttle enrichment of an off-road motorcycle is one of the most critical calculations the ECU performs and represents the core of all its strategies. The effectiveness and speed of implementation are vital in providing a reliable response to the rapid transient throttle opening and closing.

In motocross applications, the transient opening and closing of the throttle represents 80-85% of the time on track; the throttle is closed for the remaining 15-20%.

Closed-loop tuning with Lambda or AFR is not a practical strategy in motocross because of the amount of transient throttle. However, using a Lambda sensor is useful for validating the effectiveness of transient throttle enrichment strategies.

Transient corrections are unique to every map in the Spark tuning software. Four transient correction tables are available for each map; a throttle opening and closing table for both injection and ignition.

- Injection corrections are a percentage of injector pulse duration.
- Ignition corrections are an offset in degrees of spark timing.

Please review the sample transient throttle correction tables below.

### Injection correction table for transient throttle opening.

#### Injection correction for opening throttle transients

Tps (%)	2.0	3.5	4.5	9.0	15.0	20.0	25.0	30.0	35.0	37.5	40.0	45.0	50.0	60.0	70.0	80.0
Opening speed (%/s)	190	300	320	360	360	650	650	650	650	650	650	650	650	650	650	650
Correction (%)	5.0	5.0	8.0	10.0	15.0	15.0	20.0	25.0	30.0	30.0	30.0	30.0	30.0	20.0	20.0	20.0
Correction time (r)	5	5	5	5	5	5	5	5	5	5	5	5	5	5	4	4

#### Injection correction for closing throttle transients

Tps (%)	15.0	25.0	30.0	32.0	35.0	38.0	43.0	50.0	54.0	57.0	60.0	65.0	70.0	75.0	80.0	85.0
Closing speed (%/s)	-820	-750	-700	-688	-664	-650	-450	-450	-450	-450	-410	-400	-400	-400	-400	-400
Correction (%)	-40.0	-40.0	-40.0	-45.0	-45.0	-45.0	-45.0	-45.0	-45.0	-45.0	-45.0	-45.0	-45.0	-45.0	-45.0	-45.0
Correction time (r)	6	6	6	6	5	5	5	5	5	4	4	4	4	3	3	3

#### Ignition correction for opening throttle transient

Tps (%)	2.0	3.5	4.5	9.0	15.0	20.0	25.0	30.0	35.0	37.5	40.0	45.0	50.0	55.0	60.0	70.0
Opening speed (%/s)	190	300	320	600	850	950	1050	1100	1150	1200	1250	1300	1350	1400	1450	1520
Correction advance (°)	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0
Correction time (r)	1	1	1	1	1	1	1	1	1	1	1	1	1	1	1	1

#### Ignition correction for closing throttle transient

Tps (%)	20.0	25.0	30.0	32.0	35.0	38.0	43.0	50.0	54.0	57.0	60.0	65.0	70.0	75.0	80.0	85.0
Closing speed (%/s)	-820	-750	-700	-688	-664	-650	-630	-570	-540	-470	-410	-400	-400	-400	-400	-400
Correction advance (°)	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0
Correction time (r)	1	1	1	1	1	1	1	1	1	1	1	1	1	1	1	1

## Table Details:

The first column is the same structure across all tables:

- **TPS (%)** is the position of the throttle.
- **Opening/Closing Speed (% / s)** is the derivative of throttle position speed (**DTPS**), or how fast the throttle is opened or closed. It's important to note that the value is a minimum threshold for the correction to be applied.
- **DTPS** is calculated as  $v = (x2 - x1) / t$  where:
  - $v$  = speed
  - $x2$  = final throttle position
  - $x1$  = initial throttle position
  - $t$  = time interval

During throttle opening,  $x2$  will be greater than  $x1$ ; therefore, the speed will be a positive value.

During throttle closing,  $x2$  will be less than  $x1$ ; therefore, the speed will be a negative value.

**A DTPS value of 100%/s means that the throttle position moves from 0 to 100% in ONE second.**

**If the rider opens the throttle faster, the DTPS value grows. A DTPS of 200%/s means that the rider opens the throttle from 0 to 100% in half a second (100 / 0.5). Similarly, a throttle twist from 20 to 70% in half a second, a 50% change, is 100%/s ( 50 / 0.5)**

**A negative value means that the rider is closing the throttle. For example, a value of -500%/s means that the rider has closed the throttle, from 100% to 0% in 0.2 secs ( -100 / 0.2).**

**Important! The DTPS is the qualifying threshold that must be met to apply the correction.**

A data logger is required to record the value of the DTPS while the rider is on track. Analysis of the data will allow recursive fine-tuning of the transient enrichment strategy. AiM offers several data loggers, and for motocross, the Solo2 DL is the most suitable choice.

- **Correction** indicates the type of correction:
  - On the injection table, it indicates the percentage of correction to the injector pulse duration.
  - On the ignition table, it indicates the offset in degrees of spark timing.
- **Correction time (r)** is the number of engine revolutions for which the corrections are applied. For example, at 12,000 RPM, the engine rotates 200 times per second, so every revolution is five (5) milliseconds (1000 / 200). To continue with the example, if the 'correction time (r)' is set to 5 revolutions, the correction will apply for a total of 25 milliseconds (5 revs x 5 msec).

## Purpose:

The purpose of the transient throttle strategy is to avoid:

### 1) The engine stalling during the rapid opening of the throttle.

A rapid opening of the throttle will result in a large volume of air rushing into the intake with insufficient fuel to burn. Not having enough fuel to burn, the air pressure will rapidly increase in the intake duct, the lambda value will reach a lean peak, and the engine will hesitate and possibly stall. This effect is more evident at low RPM.

## 2) Engine hesitation after the rapid closing of the throttle.

When the rider quickly closes the throttle, a quantity of scheduled fuel is still delivered into the intake. The extra fuel delivered during the closing of the throttle may result in a puddle of fuel in the intake. This extra fuel can create a rich condition when the throttle is again opened, making for a hesitant engine that lacks a good throttle response.


Minimizing these two conditions will result in a predictable, ready, and consistently snappy motorcycle. Please review the injector transient correction table and corresponding data below to see this strategy at work

Tps (%)	2.0	4.5	9.0	15.0	20.0	25.0	30.0	35.0	37.5	40.0	45.0	50.0	55.0	60.0	70.0
Opening speed (%/s)	190	320	360	360	650	650	650	650	650	650	650	650	650	650	650
Correction (%)	5.0	8.0	10.0	15.0	15.0	20.0	25.0	30.0	30.0	30.0	30.0	30.0	20.0	20.0	20.0
Correction time (r)	5	5	5	5	5	5	5	5	5	5	5	5	5	4	4


Reading this table from top to bottom, looking at the area circled, we see:

- 1) An assumed value of 10% throttle opening, falling between 9 and 15% in the first row.
- 2) A throttle opening speed threshold of 360% per second in the second row.
- 3) A fuel correction between 10-15%, to be linearly interpolated, in the third row.
- 4) A correction time of 5 engine revolutions in the final row.

These screen captures of logged data give visual details of the transient throttle enrichment strategy at work.




- Orange curve: TPS
- Purple curve: DTPS (throttle opening speed)
- Green curve: INJ\_TRANS\_CORR (% injection correction of transients)
- Blue curve: ENG\_REV (motor revolution counter)
- Grey curve: lambda value
- Red curve: RPM



Above we see the data plotted over time, zoomed full screen to about 0.5 seconds.


- Circle 1 is the throttle opening.
- Circle 2 shows an increased throttle opening speed (DTPS) that exceeds the threshold value of the opening speed value expressed in the table to apply a transient injector correction.
- Circle 3 shows the percentage of injector pulse width correction applied.

*The correction is recalculated 200 times per second: when, during an opening, the DTPS value is no longer higher than the value interpolated from the table, the correction remains for the number of revolutions set in the same table. The graph below shows this effect.*



The rectangle in this graph highlights how the contribution of the injector correction (green curve) at a certain point remains constant for the number of motor revolutions set in the correction time (blue graph).

*The moment the throttle is released, the throttle lock injection transient correction table will be used. You can check the result by observing the lambda value, highlighted in the rectangle in the image above.*



When the rider closes the throttle and the DTPS closing speed exceeds the threshold value from the injection correction table for transient throttle closing in the negative direction, the fuel percentage correction is applied for the number of engine revolutions expressed in the table. The above image shows the throttle closure process (orange graph) with the effects of DTPS (purple) and injection percentage correction (green).

It is easy to see that it is necessary to add fuel during the throttle opening to prevent the engine from stalling, while during the closing, it is essential to remove fuel.

Here we can also observe that:

- The throttle went from 0 to 58% in 0.16 sec
- The RPM value went from 5527 to 10442 in the same period
- The Lambda value remained between 0.88 and 0.96 $\lambda$  without rich or lean peaks during the transient conditions.

Similar transient throttle corrections can be made for ignition timing; increasing the advance by adding a positive offset assists in increasing engine RPM to avoid a stall. However, the ignition offset is generally absent, and only in some rare cases is it appropriate to introduce a negative offset.

## Appendix J – CAN Protocols

### User CAN Protocol

Can Bus Speed: 1 Mbit Endianless: Big Endian

CAN ID	B0	B1	B2	B3	B4	B5	B6	B7
0x402			TPS		Gear			
0x403	Battery Voltage							
0x404	ECT		IAC		ECU T			
0x405	RPM							
0x40B	Usage Time Sec		Usage Time Min					
0x40C	DTPS		Inj Trans Corr		Ign Trans Corr		Eng Flag	
0x40D							Eng State	
0x40E					Map Sel		Launch State	
0x40F	Eng Diag HH	Eng Diag HL	Eng Diag LH	Eng Diag LL	Analog Diag HH	Analog Diag HL	Analog Diag LH	Analog Diag LL
0x410	Eng Rev							
0x411	Drop V		Spare CH 1		Spare CH 2			

Channel name	Gain	Offset	Sign	Measure unit
TPS	0,1	0	unsigned	%
GEAR	1	0	unsigned	#
Battery Voltage	1	0	unsigned	mV
ECT	0,1	0	signed	C
IAT	0,1	0	signed	C
ECU T	1	0	signed	C
RPM	1	0	unsigned	rpm
USAGE TIME SEC	1	0	unsigned	s
USAGE TIME MIN	1	0	unsigned	min
DTPS	1	0	signed	#
INJ TRANS CORR	0.1	-100	signed	%
IGN TRANS CORR	0.1	0	signed	deg
ENG FLAG	1	0	unsigned	#
MAP SEL	1	0	unsigned	#
LAUNCH STATE	1	0	unsigned	#
ENG DIAG HH	1	0	unsigned	#
TPS	0,1	0	unsigned	%
GEAR	1	0	unsigned	#
DTPS	1	0	signed	#
ENG DIAG HL	1	0	unsigned	#
ENG DIAG LH	1	0	unsigned	#
ENG DIAG LL	1	0	unsigned	#
ANALOG DIAG HH	1	0	unsigned	#
ANALOG DIAG HL	1	0	unsigned	#
ANALOG DIAG LH	1	0	unsigned	#
ANALOG DIAG LL	1	0	unsigned	#
ENG REV	1	0	unsigned	#
DROP V	1	0	unsigned	mV
SPARE CH 1	1	0	unsigned	mV
SPARE CH 2	1	0	unsigned	mV



## Tuner CAN Protocol

Can Bus Speed: 1 Mbit Endianless: Big Endian

CAN ID	B0	B1	B2	B3	B4	B5	B6	B7
0x400	MAP CNT		TPS CNT		BATTERY CNT		ECT CNT	
0x401	GEAR CNT		IAT CNT					
0x402	MAP		TPS		GEAR		RPM 360	
0x403	BATTERY						VREF	
0x404	ECT		IAT		ECU T		BAROMETRIC P	
0x405	RPM		IGN ADV		IGN BASE ADV		INJ TIME	
0x406	IGN ECT CORR		IGN IAT CORR		INJ ECT CORR		INJ IAT CORR	
0x407	INJ1 BASE PHASE		INJ BASE TIME		INJ1 PHASE		INJ1 TIME	
0x408	SMOT ERR CNT		INJ CRANK CORR		INJ1 BATT CORR		TRIM CORR	
0x409	IGN BAP CORR		INJ BAP CORR					
0x40A	INJ1 PERC		INJ2 PERC				INJ2 PHASE	
0x40B	INJ2 TIME		INJ2 BATT CORR		USAGE TIME SEC		USAGE TIME MIN	
0x40C	DTPS		INJ TRANS CORR		IGN TRANS CORR		ENG FLAG	
0x40D	IGN TC CORR		INJ TC CORR		ENG POS		ENG STATE	
0x40E	REF TIME				MAP SEL		LAUNCH STATE	
0x40F	ENG DIAG HH	ENG DIAG HL	ENG DIAG LH	ENG DIAG LL	ANALOG DIAG HH	ANALOG DIAG HL	ANALOG DIAG LH	ANALOG DIAG LL
0x410	ENG REV				RPM MEAN ACC			
0x411	DROP V		SPARE CH 1		SPARE CH 2			
0x412	LAMBDA							

Channel name	Gain	Offset	Sign	Measure unit
MAP CNT	1	0	unsigned	#
TPS CNT	1	0	unsigned	#
BATTERY CNT	1	0	unsigned	#
ECT CNT	1	0	unsigned	#
GEAR CNT	1	0	unsigned	#
IAT CNT	1	0	unsigned	#
MAP	1	0	unsigned	mBar
TPS	0,1	0	unsigned	%
GEAR	1	0	unsigned	#
RPM 360	1	0	unsigned	rpm
BATTERY	1	0	unsigned	mV
VREF	1	0	unsigned	mV
ECT	0,1	0	signed	C
IAT	0,1	0	signed	C
ECU T	1	0	signed	C
BAROMETRIC P	1	0	unsigned	mBar
RPM	1	0	unsigned	rpm
IGN ADV	0,1	0	signed	deg
IGN BASE ADV	0,1	0	signed	deg
INJ TIME	1	0	unsigned	us
IGN ECT CORR	0,1	0	signed	deg
IGN IAT CORR	0,1	0	signed	deg
INJ ECT CORR	0,1	-100	signed	%
INJ IAT CORR	0,1	-100	signed	%



INJ1 BASE PHASE	0,1	-360	signed	deg
INJ BASE TIME	1	0	unsigned	ms
INJ1 PHASE	0,1	-360	signed	deg
INJ1 TIME	1	0	unsigned	ms
SMOT ERR CNT	1	0	unsigned	#
INJ CRANK CORR	0,1	-100	signed	%
INJ1 BATT CORR	1	0	unsigned	ms
TRIM CORR	0,1	-100	signed	%
IGN BAP CORR	0.1	0	signed	deg
INJ BAP CORR	0,1	-100	signed	%
INJ1 PERC	0.1	0	unsigned	%
INJ2 PERC	0,1	0	unsigned	%
INJ2 PHASE	0,1	-360	signed	deg
INJ2 TIME	1	0	unsigned	us
INJ2 BATT CORR	1	0	unsigned	us
USAGE TIME SEC	1	0	unsigned	s
USAGE TIME MIN	1	0	unsigned	min
DTPS	1	0	signed	#
INJ TRANS CORR	0.1	-100	signed	%
IGN TRANS CORR	0.1	0	signed	deg
ENG FLAG	1	0	unsigned	#
IGN TC CORR	0.1	0	signed	deg
INJ TC CORR	0.1	0	signed	deg
ENG POS	1	0	unsigned	#
ENG STATE	1	0	unsigned	#
REF TIME	1	0	unsigned	us
MAP SEL	1	0	unsigned	#
LAUNCH STATE	1	0	unsigned	#
ENG DIAG HH	1	0	unsigned	#
ENG DIAG HL	1	0	unsigned	#
ENG DIAG LH	1	0	unsigned	#
ENG DIAG LL	1	0	unsigned	#
ANALOG DIAG HH	1	0	unsigned	#
ANALOG DIAG HL	1	0	unsigned	#
ANALOG DIAG LH	1	0	unsigned	#
ANALOG DIAG LL	1	0	unsigned	#
ENG REV	1	0	unsigned	#
RPM MEAN ACC	1	0	signed	#
DROP V	1	0	unsigned	mV
SPARE CH 1	1	0	unsigned	mV
SPARE CH 2	1	0	unsigned	mV
LAMBDA	0.001	0	Unsigned	lambda