

EMS Stinger V123 communication protocol

Channels received by AIM loggers connected to EMS Stinger V123 ECU are:

ID	CHANNEL NAME	FUNCTION
ECU_1	EMS_ENGINESPD	Speed
ECU_2	EMS_MAINPRESS	Main pressure
ECU_3	EMS_AFR	Air/Fuel ratio
ECU_4	EMS_IGN_TIMING	Ignition timing
ECU_5	EMS_THROTTLE	Throttle position sensor
ECU_6	EMS_INJ_MS	Injection measure
ECU_7	EMS_BATTVOLT	Battery voltage
ECU_8	EMS_ENGTEMP	Engine temperature
ECU_9	EMS_AIRTEMP	Intake air temperature